

COMDIAL

Executech™

MODEL 2232 HYBRID/KEY SYSTEM

- INSTALLATION
 - PROGRAMMING
 - MAINTENANCE

Committed to U.S. design leadership in business communications

IMI 66-047
September, 1987

INSTALLATION AND MAINTENANCE INFORMATION
FOR THE Executec MODEL 2232 KSU
HYBRID/KEY SYSTEM

SERIAL NUMBER _____

TABLE OF CONTENTS

CHAPTER 1 INTRODUCTION.....	1-1
MANUAL SCOPE.....	1-1
RELATED INFORMATION.....	1-1
STATION TYPES.....	1-2
INSTALLER/USER INFORMATION REGARDING FCC RULES AND REGULATIONS.....	1-2
RINGER EQUIVALENCE NUMBER.....	1-4
CHAPTER 2 INSTALLATION.....	2-1
MOUNTING CONSIDERATIONS.....	2-1
MOUNTING PROCEDURE.....	2-1
SYSTEM WIRING.....	2-3
SYSTEM CHECKOUT.....	2-17
CHAPTER 3 SYSTEM PROGRAMMING.....	3-1
GENERAL INFORMATION.....	3-1
SPECIAL PROGRAMMING REQUIREMENTS FOR SINGLE-LINE KEYSETS.....	3-2
BASE LEVEL PROGRAM ENTRY MODE.....	3-2
CLASS OF SERVICE DEFAULT.....	3-3
PROGRAMMING OVERLAYS.....	3-3
SYSTEM COS PROGRAMMING PROCEDURE.....	3-5
SYSTEM COS PROGRAMMING REFERENCE TABLE.....	3-7
TOLL RESTRICTION PROGRAMMING.....	3-9
TOLL RESTRICTION PROGRAMMING REFERENCE TABLE.....	3-10
LINE COS PROGRAMMING.....	3-12
LINE COS PROGRAMMING REFERENCE TABLE.....	3-13
STATION COS PROGRAMMING.....	3-14
STATION COS PROGRAMMING REFERENCE TABLE.....	3-19
COS AND SMDR PRINTOUT.....	3-20
CASSETTE TAPE RECORD OF COS VALUES.....	3-22
SYSTEM CLOCK INFORMATION.....	3-24
SYSTEM SPEED DIAL PROGRAMMING.....	3-25
PROGRAMMING REFERENCE FLOW CHART.....	3-26
CHAPTER 4 MAINTENANCE.....	4-1
TECHNICAL ASSISTANCE AND REPAIR SERVICE.....	4-1
FUSE LOCATION.....	4-1
FAILURE ISOLATION.....	4-2
DESK/WALL REVERSAL AND WALL MOUNTING.....	4-7
REPLACEMENT PARTS LIST.....	4-9
PUBLICATION INDEX.....	I-1

LIST OF ILLUSTRATIONS

Figure 2-1. KSU Mounting Dimensions.....2-2
 Figure 2-2. Common Audible/Auxiliary Station Interface.....2-14
 Figure 2-3. PA Connections.....2-14
 Figure 2-4a. System Interconnection-Typical Connections.....2-15a
 Figure 2-4b. System Interconnection-Typical Connections.....2-15b
 Figure 2-5. Typical 6-Wire, Auxiliary-Pair Wiring.....2-16
 Figure 3-1. Programming Overlay Details.....3-4
 Figure 3-2. SMDR Printout Details.....3-20
 Figure 3-3a. Programming Procedures Reference Chart.....3-26
 Figure 3-3b. Programming Procedures Reference Chart.....3-27
 Figure 4-1. Fuse Locations And Values.....4-2
 Figure 4-2. Failure Analysis Flow Chart.....4-6
 Figure 4-3. Station Wall Mounting Details.....4-8

LIST OF TABLES

Table 2-1. Wiring For Station Connector Block J-1.....2-9
 Table 2-2. Wiring For Station Connector Block J-2.....2-10
 Table 2-3. Wiring For Station Connector Block J-3.....2-11
 Table 2-4. Wiring For Auxiliary Connector Block J-4.....2-12
 Table 2-5. Wiring For CO/PBX Connector Block J-5.....2-13

CHAPTER 1 INTRODUCTION

MANUAL SCOPE

This publication contains installation, programming, and maintenance information for the Model 2232 KSU electronic key **system** and associated electronic **key** telephone stations.

NOTE

Minor corrections and up-dates have been added to this manual. They are noted where applicable on pages 1-1, 2-4, 2-9, 2-18, 3-5, and 3-8.

This **key** system is fully protected, and therefore the installation does not require the services of an authorized agent. However, the installation procedures detailed in this manual should only be performed by individuals familiar with general telephone installation procedures.

The end user may perform routine maintenance procedures, such as the following listed ones, but all other servicing must be performed by factory authorized personnel.

@Place or replace any designation strips on the face of the telephone stations.

@Replace the line cord or handset coiled cord.

- Replace complete stations and station handsets. The handset is a special Comdial type. Other handset types will not work properly.
- Relocate the station when it is plugged into the proper **system jacks**.

RELATED INFORMATION

- IMI 01-001, Compliance Requirements To FCC Rules and Regulations Part 68 and 15
- IMI 01-005, Handling Of Electrostatically Sensitive Components
- GCA 40-028, General Information, Electronic Key System
- GCA 70-057, User's Guide for Multiline Station
- GCA 70-058, User's Guide for Single Line Station
- GCA 70-066, User's Guide for DSS/BLF Console
- GCA 48-002, Service Policy

STATION TYPES

This Key Service Unit supports the operation of the following stations:

- 22 Line/Feature Keypad
- Reused 3/8 Line Keypad
- Single-Line Keypad
- DSS/BLF Console 32-Key, 40-Key, and 70-Key

INSTALLER/USER INFORMATION
REGARDING FCC RULES AND REGULATIONS

This electronic key system complies with Federal Communications Commission (FCC) Rules, Part 68.

The FCC registration label on the KSU contains the FCC registration number, the ringer equivalence number, the model number, and the serial number or production date of the system.

NOTIFICATION TO TELEPHONE COMPANY

Unless a telephone operating company provides and installs the system, the telephone operating company which provides the lines must be notified before a connection is made to them. The lines (telephone numbers) involved, the FCC registration number, and the ringer equivalence number must be provided to the telephone company. The FCC registration number and the ringer equivalence number of this equipment are provided on the label attached to the KSU.

The user/installer is required to notify the telephone company when final disconnection of this equipment from the telephone company line occurs.

DUAL REGISTRATION NOTIFICATION

This equipment can be hardware configured by the installer/dealer as either a key system or as a multifunction (hybrid) system. Configuration procedures can be found in the installation section of this publication. Because of this versatility, the FCC has granted a dual registration to the system. The installer/dealer must notify the telephone operating company of the new or changed registration number that reflects the configuration that this equipment is currently arranged to provide. The installer/dealer may be required to certify in writing to the telephone operating company how the system is configured. The telephone operating company may conduct an on-site inspection to verify the system configuration.

COMPATIBILITY WITH TELEPHONE NETWORK

When necessary, the telephone operating company provides information on the maximum number of telephones or ringers that can be connected to one line, as well as any other applicable technical information. The telephone operating company can temporarily discontinue service and make changes which could effect the operation of this equipment. They must, however, provide adequate notice, in writing, of any future equipment changes that would make the system incompatible.

INSTALLATION REQUIREMENTS

Connection of the electronic key system to the telephone lines must be through a universal service order code (USOC) outlet jack supplied by the telephone operating company. If the installation site does not have the proper outlet, ask the telephone company business office to install one. The correct outlet jack for this system is a type RJ21X.

PARTY LINES AND COIN LINES

Local telephone company regulations may not permit connections to party lines and coin lines by anyone except the telephone operating company.

TROUBLESHOOTING

If a service problem occurs, first try to determine if the trouble is in the on-site system or in the telephone company equipment. Disconnect all equipment not owned by the telephone company. If this corrects the problem, the faulty equipment must not be reconnected to the telephone line until the problem has been corrected. Any trouble that causes improper operation of the telephone network may require the telephone company to discontinue service to the trouble site after they notify the user of the reason.

REPAIR AUTHORIZATION

FCC regulations do not permit repair of customer owned equipment by anyone except the manufacturer, their authorized agent, or others who might be authorized by the FCC. However, routine repairs can be made according to the maintenance instructions in this publication, provided that all FCC restrictions are obeyed.

RADIO FREQUENCY INTERFERENCE

The electronic key system contains incidental radio frequency generating circuitry and, if not installed and used properly, may cause interference to radio and television reception. This equipment has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules. These limits are designed to provide reasonable protection against such interference when operated in a commercial environment.

Operation of this equipment in a residential area may cause interference to radio and television reception; in which case the user is encouraged to **take** whatever measures may be required to correct the interference.

If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and **on**, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient the television or radio's receiving antenna, and/or relocate the KSU, the individual telephone stations, and the radio **or** TV with respect to each other.

If necessary, the user should consult the manufacturer or an experienced radio/television technician for additional suggestions. The user may find the following booklet prepared by the Federal Communications Commission helpful: "How to Identify and Resolve Radio-TV Interference Problems." This booklet is available from the Government Printing Office, Washington D.C. 20402. **Stock No. 004-000-00345-4.**

RINGER EQUIVALENCE NUMBER

The REN of each line of the **KSU is 0.4B.** The FCC requires the installer to determine the total REN for each line, and record it at the equipment.

CHAPTER 2 INSTALLATION

MOUNTING CONSIDERATIONS

- The KSU and power supply cabinets should **be** attached vertically to any sturdy, flat, surface. They may be vertically rack mounted if desired. The power supply cabinet can be mounted so that the power connector and fuses are facing either toward the right side or toward the left side of the mounting location.
- The power interconnection cable is four feet in length. Locate the cabinets with respect to each other so that this cable will reach between the cabinet connectors. Do not locate the cabinets closer than within six inches of each other.
- The power supply **must be** located within six (6) feet of a proper electrical outlet. The power supply requires a dedicated 117VAC 15 AMP circuit, with a third-wire ground, supplied to a NEMA 5-15R electrical outlet.
- The distance between the KSU and the TELCO/PBX **jacks must be 25** feet or less as per FCC requirements. A nominal distance of 7 feet is recommended.
- The mounting location **must be** secure and dry and have **adequate** ventilation. The temperature range of the location must be within 32-122degrees F (0-50 degrees C), and the relative **humidity must be** less than 90 percent non-condensing.
- If the mounting surface is damp or if it is concrete or masonry material, a backboard must **be** attached to the mounting surface to be used for **KSU** mounting. Suitable mounting backboards are **available** commercially or can be constructed **out** of 1/2-inch plywood cut to size.

Tools and hardware required for mounting the KSU cabinet include:

- @Fasteners - wood screws (1/4 x 1-inch round head), toggle **bolts**, or wall anchors
- *Screwdriver - to match fasteners
- @Electric drill - if prepared holes are required
- Connecting tool - for fastening wires to a type-66 connector **block**.
- @Crimping tool - for 623-type modular plugs

MOUNTING PROCEDURE

1. Unpack, and carefully inspect the KSU, power supply, and stations for shipping damage. Notify the shipper immediately of any damages found. Verify that the packages contain all parts and accessories needed for proper installation and operation.
2. If a backboard is required at the mounting location, attach it securely to provide **a stable** mounting surface for the equipment.

3. Full scale mounting templates are supplied in the packing boxes. Hold or tape them to the mounting **surface**, and mark the location of the mounting holes on the mounting surface as they are located on the templates. The mounting dimensions and general equipment locations are shown on Figure 2-1.
4. Drill holes in the mounting surface of a proper size to accommodate the hardware being used. If necessary, prepare these holes with inserts, anchors or other attachment devices as dictated by the type of mounting surface.
5. Attach the KSU and power supply cabinets to the mounting surface with four (4) screws installed through the KSU mounting flange and into the mounting surface holes. Note that the flange holes are elongated with an enlargement at one end. This feature allows the mounting screws to be partially installed in the mounting surface before the cabinets are hung on them. The flange holes on the power supply cabinet have an enlargement at the center of the elongated holes to allow the cabinet to be mounted with the power connector and fuses facing either toward the right side or toward the left side of the mounting location.
6. Place the individual telephone stations as desired and in keeping with accepted industry and office standards. A telephone station can be wall mounted if necessary as they are desk/wall reversible. Refer to Chapter 4, Maintenance, for instructions in preparing a desk/wall reversible station for wall mounting.




Figure 2-1. Mounting Dimensions'

SYSTEM WIRING

System cabling may be routed concealed or visible as the installation location requires. Good engineering practices must be observed and all applicable building codes must be adhered to. Tables 2-1 through 2-5 and Figures 2-2 through 2-5 illustrate the system wiring and connection points.

AC Power Connection

Connect the power interconnection cable between the power supply and the KSU.

CAUTION

Do not connect or disconnect the power interconnection cable while the AC power cord is connected to the AC outlet.

To apply AC power to the power supply, connect the AC power cord to the NEMA 5-15R outlet which supplies the dedicated 117VAC @ 15 AMP electrical power. A plug-in, power line surge protector should be installed between the KSU power cord and the AC outlet.

CAUTION

Do not connect the AC power cord until the installation has been checked per the SYSTEM CHECKOUT instructions given later in this chapter.

Line Connections

The KSU interface connection for the TELCO or PBX lines is a 50-pin, male connector. A 25-pair cable, properly terminated, must be connected from the KSU connector to the demarcation point connector (typically a 66M-xx connector).

CAUTION

To help insure that foreign voltages, which could appear on the TELCO lines, do not damage the system, verify that gas discharge tubes or similar protection devices are installed, and properly grounded, in all connected TELCO lines.

Station Connections

Connections between the KSU and the stations are typically via type 66M-xx connector blocks which are cable connected to the KSU 50-pin male connector. The maximum distance allowed from the KSU to the station is 1500 feet using #24 gauge, twisted-pair cable.

If spare conductors exist in the cables that are run between the KSU 66M-xx connector block and the station jacks, it is a good practice to connect them to earth ground. Doing this may help prevent them from inducing radio frequency and/or AC interference into the system.

CAUTION

The polarity between the individual wires in a particular voice or data pair is not critical; however, do not connect the voice circuits to the data circuits.

IMPORTANT NOTE

Station ports are programmed for the type of equipment that is to be connected to them. A 22 Line/Feature **Keyset** must be installed at station port 10 and/or station port 11 as Class Of Service programming is performed from those ports.

DSS/BLF Console Connections

The system provides two console ports. The console ports are associated with companion station ports as follows:

CONSOLE PORT	STATION PORT
10	10
11	11

Power Failure Station Connections

The system provides four tip and ring pairs connected to lines 1, 2, 3, and 4 as emergency, power failure circuits. These power failure pairs are located as detailed on Table 2-4 and Figure 2-4. A power failure pair is only active during a power failure. An industry standard, single-line telephone, such as a type 2500, can be connected to a power failure pair and used to provide communications capability should the AC power to the system be interrupted.

Station Auxiliary Jack Connections

For those stations equipped with an auxiliary jack, pins 3 and 4 (tip and ring leads) of this jack are connected to pins 1 and 6 of the station line jack. A 6-conductor station line cord is used, and the third pair is designated as the auxiliary-pair.

Refer to Figure 2-5 for an illustration of a typical auxiliary-pair wiring connection, and note the following wiring considerations:

- **Wire** a type 625A2-6 modular jack to be used as the station wall jack.
- @Connect 3-pair cable between the station wall jack and an auxiliary 66M-xx connector block.
- Connect the voice-pair and data-pair from the auxiliary connector block to the station connector block.

*Connect the auxiliary-pair from the auxiliary connector block to the desired termination.

@Connect an appropriate line cord between the auxiliary jack and the auxiliary source equipment.

A-Lead Control Device Connections

The KSU can detect an A-lead (A and A1) control signal when it is applied to lines 13 - 16. An A-lead control device can be bridge-connected to these lines via terminal clips on the J-4 station connector block. Refer to Table 2-4 and Figure 2-4 for connection details.

Data Device Connections

When a serial data printer is used for SMDR and COS printout, or a video display terminal (VDT) is used to perform class of service programming connect the data device to terminal clips on the J-4 auxiliary connector block. The maximum distance between the device and the KSU must not exceed 50 feet. Refer to Table 2-4 for connection details.

When preparing a cable for connection to a data device, refer to the manufacturer's manual for the equipment being interfaced, and make the following wiring connections:

- Wire the KSU RD line (data from device to KSU) to the device TD (transmit data) output pin.
- @Wire the KSU TD (data to device from KSU) pin to the device RD (receive data) pin.
- Wire the KSU SG (signal ground) pin to the device SG (signal ground) pin.
- Wire the KSU CTS (clear-to-send status from device to KSU) pin to the device RTS (request-to-send) output pin. NOTE: The KSU requires a positive voltage, with respect to signal ground, in order to send data.
- If required, wire the KSU RTS (request-to-send status signal from the KSU to the device) pin to the device DSR (data-set-ready) input pin.
- If required, wire the KSU PG (protective ground) line(s) to the device protective ground pin(s).

The system defaults to 7-bit data with no parity at a baud rate of 1200. Configure the device, per the manufacturer's instructions, to match the data format and baud rate that is set by COS programming.

System n d i n g

It is required that a grounding wire, separate from the three wire AC line cord, be used. A ground stud is located on the KSU and on the power supply for this purpose. Wire #10 or #12, insulated, solid copper wires between these ground studs and a reliable earth ground such as a metal cold water pipe or a building frame ground.

Common Audible and Auxiliary Station Interface

Two sets of relay closure dry-contact points are available at the J-1 and J-2 station connector blocks.

- One set (J-1 connections) provides a dry-contact closure whenever any of the TELCO/PBX lines, connected to the KSU, ring.
- The other set (J-2 connections) provides a dry-contact closure whenever system station port 17 rings.

These contact closures track the ringing pattern in both cases. The contacts are closed during the ringing period and are open during the silent period.

A typical connection is illustrated in Figure 2-2. Refer to the paragraph headed Area Paging Interface for a discussion for using these terminals i-is-alternate paging function.



Do not exceed a 1 amp at 24 volts (.5 amp at 48 volts) load on these control terminals. If the load requirements exceed this limit, connect the load through an external slave relay. DO NOT CONNECT THESE CONTROL TERMINALS DIRECTLY TO THE 117VAC LINE.

Area Paging Interface - Station PA Port

Any unused station port can be programmed to be a PA port instead of a telephone station port (see Chapter 3 for programming details).

- The audio input of an external paging amplifier can be connected to the audio pair of the station port as illustrated in Figure 2-3.
- The audio input connection must be isolated with a 600 ohm to 600 ohm audio matching transformer. Terminate the audio input of the PA system with a 620 ohm (nominal value) resistor.
- If station port 39 is programmed as a PA port, the Common Audible contact points are automatically reconfigured as PA enable terminals. The contact closure now occurs when PA station 39 is dialed. The normal common audible function, as discussed previously, is disabled as long as station 39 is a PA station.
- If station port 41 is programmed as a PA port, the Auxiliary Station Interface (station port 17 audible) contact points are automatically reconfigured as PA enable terminals. The contact closure now occurs when PA station port 41 is dialed. The normal auxiliary station interface function, as discussed previously, is disabled as long as station port 41 is a PA station.

Area Paging Interface - Line Port

A line port can be configured by class of service programming to be an AUXILIARY port. As an AUXILIARY port, it can be used to couple a station voice path to an external device. This is done from any allowed station by pressing the proper line key to select the AUXILIARY port. DTMF tones or dial pulses can be dialed through the auxiliary port as needed.

If direct access area paging is to be part of the system, connect the audio input of a paging amplifier to the line that is programmed to be an AUXILIARY port. The input impedance of this port is approximately 600 ohms. A tone select, zone-paging amplifier can be employed if desired. If used, the zone-select code must be dialed after the AUXILIARY port line select key is pressed.

Key System/Multifunction (Hybrid) Configuration

The system can be configured to operate as either a key system or as a multifunction (hybrid) system.

Configuration is by way of a wire strap placed between clip terminals 27 and 28 of station connector block J-4.

The KSU is shipped from the factory as a key system (KF). To convert operation over to the multifunction (MF) system, add the strap.

The KF and MF designations are equipment type **categories** as stipulated in FCC rules and regulations, Part 68, and appear as part of the FCC Registration Number on the equipment label. The appropriate registration number must be reported to the telephone company at the time of connection along with other FCC mandated information. (Refer to Installer/User Information Regarding FCC Rules and Regulations found in Chapter 1 of this manual.)

Operationally, the multifunction (hybrid) configuration enables a PBX feature which may incur a higher monthly tariff to the telephone company. This feature allows dial access to (automatic selection of) outgoing lines. The specific Executech feature that is enabled by the multifunction (hybrid) configuration is:

- Line Group (Including Dial Access)

Music Interface

If music is to be part of the system, connect a KX registered music source to the KSU input jack (phono jack) provided for this purpose. The impedance of this input is approximately 500 ohms. Level adjustment of the music source may be necessary. This may be done during system checkout.

Cassette Tape Recorder Interface

A customer provided, audio cassette, tape recorder can be connected to the music interface jack. Class of service programming can be both stored and loaded via the recorder through this interface. This action is controlled from station 10 as detailed in Chapter 3, System Programming.

Table 2-1. Wiring For Station Connector Block J-1

SYSTEM INTERCONNECTION FOR KSU J1						
KSU INTERFACE CONNECTOR WIRING			CONNECTION BLOCK WIRING			
25-PAIR CABLE CONNECTIONS			ASSIGNMENT (DEFAULT EXTENSION SHOWN)		4-WIRE CABLE CONNECTIONS	
WIRE COLOR	PAIR	PIN NO.			COLOR	CLIP TERM.
WHITE-BLUE	1	26	STATION PORT 10	VOICE PAIR	GREEN	1
BLUE-WHITE		1			RED	2
WHITE-ORANGE	2	27	EXT. 110	DATA PAIR	YELLOW	3
ORANGE-WHITE		2			BLACK	4
WHITE-GREEN	3	28	CONSOLE PORT 10	POWER PAIR	GREEN	5
GREEN-WHITE		3			RED	6
WHITE-BROWN	4	29	DATA PAIR	DATA PAIR	YELLOW	7
BROWN-WHITE		4			BLACK	8
WHITE-SLATE	5	30	STATION PORT 11	VOICE PAIR	GREEN	9
SLATE-WHITE		5			RED	10
RED-BLUE	6	31	EXT. 111	DATA PAIR	YELLOW	11
BLUE-RED		6			BLACK	12
RED-ORANGE	7	32	RESERVED		GREEN	13
ORANGE-RED		7			RED	14
RED-GREEN	8	33	RESERVED		YELLOW	15
GREEN-RED		A			BLACK	16
RED-BROWN	9	34	STATION PORT 12	VOICE PAIR	GREEN	17
BROWN-RED		9			RED	18
RED-SLATE	10	35	EXT. 112	DATA PAIR	YELLOW	19
SLATE-RED		10			BLACK	20
BLACK-BLUE	11	36	CONSOLE PORT 11	POWER PAIR	GREEN	21
BLUE-BLACK		11			REP	22
BLACK-ORANGE	12	37	DATA PAIR	DATA PAIR	YELLOW	23
ORANGE-BLACK		12			BLACK	24
BLACK-GREEN	13	38	STATION PORT 13	VOICE PAIR	GREEN	25
GREEN-BLACK		13			RED	26
BLACK-BROWN	14	39	EXT. 113	DATA PAIR	YELLOW	27
BROWN-BLACK		14			BLACK	28
BLACK-SLATE	15	40	RESERVED		GREEN	29
SLATE-BLACK		15			RED	30
YELLOW-BLUE	16	41	RESERVED		YELLOW	31
BLUE-YELLOW		16			BLACK	32
YELLOW-ORANGE	17	42	STATION PORT 14	VOICE PAIR	GREEN	33
ORANGE-YELLOW		17			RED	34
YELLOW-GREEN	18	43	EXT. 114	DATA PAIR	YELLOW	35
GREEN-YELLOW		18			BLACK	36
YELLOW-BROWN	19	44	STATION PORT 15	VOICE PAIR	GREEN	37
BROWN-YELLOW		19			RED	38
YELLOW-SLATE	20	45	EXT. 115	DATA PAIR	YELLOW	39
SLATE-YELLOW		20			BLACK	40
VIOLET-BLUE	21	46	STATION PORT 16	VOICE PAIR	GREEN	41
BLUE-VIOLET		21			REP	42
VIOLET-ORANGE	22	47	EXT. 116	DATA PAIR	YELLOW	43
ORANGE-VIOLET		22			BLACK	44
VIOLET-GREEN	23	48	STATION PORT 17	VOICE PAIR	GREEN	45
GREEN-VIOLET		23			RED	46
VIOLET-BROWN	24	49	EXT. 117	DATA PAIR	YELLOW	47
BROWN-VIOLET		24			BLACK	48
VIOLET-SLATE	25	50	COMMON AUDIBLE		GREEN	49
SLATE-VIOLET		25			RED	50

Table 2-2. Wiring For Station Connector Block J-2

SYSTEM INTERCONNECTION FOR KSU J2					
KSU INTERFACE CONNECTOR WIRING			CONNECTION BLOCK WIRING		
25-PAIR CABLE CONNECTIONS			ASSIGNMENT (DEFAULT EXTENSION SHOWN)	4-WIRE CABLE CONNECTIONS	
WIRE COLOR	PAIR	PIN NO.		COLOR	CLIP TERM.
WHITE-BLUE	1	26	STATION PORT 18	VOICE PAIR	GREEN 1
BLUE-WHITE		1			EXT. 118
WHITE-ORANGE	2	27	STATION PORT 19	DATA PAIR	
ORANGE-WHITE		2			EXT. 119
WHITE-GREEN	3	28	STATION PORT 20	POWER PAIR	
GREEN-WHITE		3			EXT. 120
WHITE-BROWN	4	29	STATION PORT 21	DATA PAIR	
BROWN-WHITE		4			EXT. 121
WHITE-SLATE	5	30	STATION PORT 22	VOICE PAIR	
SLATE-WHITE		5			EXT. 122
RED-BLUE	6	31	STATION PORT 23	DATA PAIR	
BLUE-RED		6			EXT. 123
RED-ORANGE	7	32	STATION PORT 24	VOICE PAIR	
ORANGE-RED		7			EXT. 124
RED-GREEN	8	33	STATION PORT 25	DATA PAIR	
GREEN-RED		8			EXT. 125
RED-BROWN	9	34	STATION PORT 26	VOICE PAIR	
BROWN-RED		9			EXT. 126
RED-SLATE	10	35	STATION PORT 27	DATA PAIR	
SLATE-RED		10			EXT. 127
BLACK-BLUE	11	36	STATION PORT 28	VOICE PAIR	
BLUE-BLACK		11			EXT. 128
BLACK-ORANGE	12	37	STATION PORT 29	DATA PAIR	
ORANGE-BLACK		12			EXT. 129
BLACK-GREEN	13	38	STATION PORT 30	VOICE PAIR	
GREEN-BLACK		13			EXT. 130
BLACK-BROWN	14	39	STATION PORT 31	DATA PAIR	
BROWN-BLACK		14			EXT. 131
BLACK-SLATE	15	40	STATION PORT 32	VOICE PAIR	
SLATE-BLACK		15			EXT. 132
YELLOW-BLUE	16	41	STATION PORT 33	DATA PAIR	
BLUE-YELLOW		16			EXT. 133
YELLOW-ORANGE	17	42	STATION PORT 34	VOICE PAIR	
ORANGE-YELLOW		17			EXT. 134
YELLOW-GREEN	18	43	STATION PORT 35	DATA PAIR	
GREEN-YELLOW		18			EXT. 135
YELLOW-BROWN	19	44	STATION PORT 36	VOICE PAIR	
BROWN-YELLOW		19			EXT. 136
YELLOW-SLATE	20	45	STATION PORT 37	DATA PAIR	
SLATE-YELLOW		20			EXT. 137
VIOLET-BLUE	21	46	STATION PORT 38	VOICE PAIR	
BLUE-VIOLET		21			EXT. 138
VIOLET-ORANGE	22	47	STATION PORT 39	DATA PAIR	
ORANGE-VIOLET		22			EXT. 139
GREEN-VIOLET	23	48	STATION PORT 40	VOICE PAIR	
VIOLET-GREEN		23			EXT. 140
VIOLET-BROWN	24	49	STATION PORT 41	DATA PAIR	
BROWN-VIOLET		24			EXT. 141
VIOLET-SLATE	25	50	STATION 17	AUXILIARY INTERFACE	
SLATE-VIOLET		25			EXT. 142

Table 2-3. Wiring For Station Connector Block J-3

KSU INTERFACE CONNECTOR WIRING			CONNECTION BLOCK WIRING					
25-PAIR CABLE CONNECTIONS			ASSIGNMENT (DEFAULT EXTENSION SHOWN)		4-WIRE CABLE CONNECTIONS			
WIRE COLOR	PAIR	PIN NO.			COLOR	WIRE TERM.		
WHITE-BLUE	1	26	STATION PORT	VOICE PAIR	GREEN	1		
BLUE-WHITE						RED	2	
WHITE-ORANGE	2	27	30 / EXT.	DATA PAIR	YELLOW	3		
ORANGE-WHITE					2	130	BLACK	4
WHITE-GREEN	3	28	STATION PORT	VOICE PAIR	GREEN	5		
GREEN-WHITE		3				RED	6	
WHITE-BROWN		29				31 EXT.	DATA PAIR	YELLOW
BROWN-WHITE	4	A			BLACK	8		
WHITE-SLATE	5	30	STATION PORT	VOICE PAIR	GREEN	9		
SLATE-WHITE		5					RED	10
RED-BLUE	6	31	32 EXT.	DATA PAIR	YELLOW	11		
BLUE-RED		6				132	BLACK	12
RED-ORANGE	7	32	STATION PORT	VOICE PAIR	GREEN	13		
ORANGE-RED		7					RED	14
RED-GREEN		33				33 EXT.	DATA PAIR	YELLOW
GREEN-RED	8	8			BLACK	16		
RED-BROWN	9	34	STATION PORT	VOICE PAIR	GREEN	17		
BROWN-RED		9					RED	18
RED-SLATE	10	35	34 EXT.	DATA PAIR	YELLOW	19		
SLATE-RED		10				134	BLACK	20
BLACK-BLUE	11	36	STATION PORT	VOICE PAIR	GREEN	21		
BLUE-BLACK		11					RED	22
BLACK-ORANGE	12	37	35 / EXT.	DATA PAIR	YELLOW	23		
ORANGE-BLACK		12				135	BLACK	24
BLACK-GREEN	13	38	STATION PORT	VOICE PAIR	GREEN	25		
GREEN-BLACK		13					RED	26
BLACK-BROWN	14	39	36 EXT.	DATA PAIR	YELLOW	27		
BROWN-BLACK		14				136	BLACK	28
BLACK-SLATE	15	40	STATION PORT	VOICE PAIR	GREEN	29		
SLATE-BLACK		15					RED	30
YELLOW-BLUE	16	41	37 EXT.	DATA PAIR	YELLOW	31		
BLUE-YELLOW		16				137	BLACK	32
YELLOW-ORANGE	17	42	STATION PORT	VOICE PAIR	GREEN	33		
ORANGE-YELLOW		17					RED	34
YELLOW-GREEN	18	43	38 EXT.	DATA PAIR	YELLOW	35		
GREEN-YELLOW		18				138	BLACK	36
YELLOW-BROWN	19	44	STATION PORT	VOICE PAIR	GREEN	37		
BROWN-YELLOW		19					RED	38
YELLOW-SLATE	20	45	39 EXT.	DATA PAIR	YELLOW	39		
SLATE-YELLOW		20				139	BLACK	40
VIOLET-BLUE	21	46	STATION PORT	VOICE PAIR	GREEN	41		
BLUE-VIOLET		21					RED	42
VIOLET-ORANGE	22	47	40 EXT.	DATA PAIR	YELLOW	43		
ORANGE-VIOLET		22				140	BLACK	44
VIOLET-GREEN	23	48	STATION PORT	VOICE PAIR	GREEN	45		
GREEN-VIOLET		23					RED	46
VIOLET-BROWN	24	49	41 EXT.	DATA PAIR	YELLOW	47		
BROWN-VIOLET		24				141	BLACK	48
VIOLET-SLATE	25	50	SPARE		GREEN	49		
SLATE-VIOLET		25					RED	50

Table 2-4. Wiring For Auxiliary Connector Block J-4

SYSTEM INTERCONNECTION FOR KSU J4							
KSU INTERFACE CONNECTOR WIRING				CONNECTION BLOCK WIRING			
25-PAIR CABLE CONNECTIONS				ASSIGNMENT (DEFAULT EXTENSION SHOWN)		4-WIRE CABLE CONNECTIONS	
WIRE COLOR	PAIR	PIN NO.			COLOR	CLIP TERM.	
WHITE-BLUE	1	26	POWER FAIL	TIP		1	
BLUE-WHITE		1	STA. 1	RING		2	
WHITE-ORANGE	2	27	POWER FAIL	RING		3	
ORANGE-WHITE		2	STA. 2	TIP		4	
WHITE-GREEN	3	28	POWER FAIL	TIP		5	
GREEN-WHITE		3	STA.3	RING		6	
WHITE-BROWN	4	29	POWER FAIL	TIP		7	
BROWN-WHITE		4	STA. 4	RING		8	
WHITE-SLATE	5	30	AUX. EQUIP.	TIP	GREEN	9	
SLATE-WHITE		5	INTERFACE	RING	RED	10	
RED-BLUE	6	31	T O	A	YELLOW	11	
BLUE-RED		6	CO LINE 13	A1	BLACK	12	
RED-ORANGE	7	32	AUX. EQUIP.	TIP	GREEN	13	
ORANGE-RED		7	INTERFACE	RING	RED	14	
RED-GREEN	8	33	T O	A	YELLOW	15	
GREEN-RED		8	CO LINE 14	A1	BLACK	16	
RED-BROWN	9	34	AUX. EQUIP.	TIP	GREEN	17	
BROWN-RED		9	INTERFACE	RING	RED	18	
RED-SLATE	10	35	T O	A	YELLOW	19	
SLATE-RED		10	CO LINE 15	A1	BLACK	20	
BLACK-BLUE	11	36	AUX. EQUIP.	TIP	GREEN	21	
BLACK-ORANGE		11	INTERFACE	RING	RED	22	
ORANGE-BLACK	12	37	T O	A	YELLOW	23	
BLACK-ORANGE		12	CO LINE 16	A1	BLACK	24	
BLACK-GREEN	13	38	SPARE			25	
GREEN-BLACK		13				26	
BLACK-BROWN	14	39	KEY/MULTIFUNCTION STRAP (OUT FOR KEY)			27	
BROWN-BLACK		14				28	
BLACK-SLATE	15	40	SPARE			29	
SLATE-BLACK		15				30	
YELLOW-BLUE	16	41	RESERVED			31	
BLUE-YELLOW		16				32	
YELLOW-ORANGE	17	42	RESERVED			33	
ORANGE-YELLOW		17				34	
YELLOW-GREEN	18	43	RESERVED			35	
GREEN-YELLOW		18				36	
YELLOW-BROWN	19	44	SPARE			37	
BROWN-YELLOW		19				38	
YELLOW-SLATE	20	45	SMDR PRINTER INTERFACE	RD		39	
SLATE-YELLOW		20		SPARE		40	
VIOLET-BLUE	21	46		TD		41	
BLUE-VIOLET		21		SG		42	
VIOLET-ORANGE	22	47		RTS		43	
ORANGE-VIOLET		22		CTS		44	
VIOLET-GREEN	23	48	PG		45		
GREEN-VIOLET		23	PG		46		
VIOLET-BROWN	24	49	SPARE			47	
BROWN-VIOLET		24				48	
VIOLET-SLATE	25	50	SPARE			49	
SLATE-VIOLET		25				50	

2
3
7
20

Table 2-5. Wiring For CO/PBX Connector Block J-5

SYSTEM INTERCONNECTION FOR KSU J5						
KSU INTERFACE CONNECTOR WIRING			CONNECTION BLOCK WIRING			
25-PAIR CABLE CONNECTIONS			ASSIGNMENT (DEFAULT EXTENSION SHOWN)	4-WIRE CABLE CONNECTIONS		
WIRE COLOR	PAIR	PIN NO.		COLOR	CLIP TERM.	
WHITE-BLUE	1	26	CO LINE 1	TIP		1
BLUE-WHITE		1		RING		2
WHITE-ORANGE	2	27	CO LINE 2	TIP		3
ORANGE-WHITE		2		RING		4
WHITE-GREEN	3	28	CO LINE 3	TIP		5
GREEN-WHITE		3		RING		6
WHITE-BROWN	4	29	CO LINE 4	TIP		7
BROWN-WHITE		4		RING		8
WHITE-SLATE	5	30	CO LINE 5	TIP		9
SLATE-WHITE		5		RING		10
RED-BLUE	6	31	CO LINE 6	TIP		11
BLUE-RED		6		RING		12
RED-ORANGE	7	32	CO LINE 7	TIP		13
ORANGE-RED		7		RING		14
RED-GREEN	8	33	CO LINE 8	TIP		15
GREEN-RED		8		RING		16
RED-BROWN	9	34	CO LINE 9	TIP		17
BROWN-RED		9		RING		18
RED-SLATE	10	35	CO LINE 10	TIP		19
SLATE-RED		10		RING		20
BLACK-BLUE	11	36	CO LINE 11	TIP		21
BLUE-BLACK		11		RING		22
BLACK-ORANGE	12	37	CO LINE 12	TIP		23
ORANGE-BLACK		12		RING		24
BLACK-GREEN	13	38	CO LINE 13	TIP		25
GREEN-BLACK		13		RING		26
BLACK-BROWN	14	39	CO LINE 14	TIP		27
BROWN-BLACK		14		RING		28
BLACK-SLATE	15	40	CO LINE 15	TIP		29
SLATE-BLACK		15		RING		30
YELLOW-BLUE	16	41	CO LINE 16	TIP		31
BLUE-YELLOW		16		RING		32
YELLOW-ORANGE	17	42	CO LINE 17	TIP		33
ORANGE-YELLOW		17		RING		34
YELLOW-GREEN	18	43	CO LINE 18	TIP		35
GREEN-YELLOW		18		RING		36
YELLOW-BROWN	19	44	CO LINE 19	TIP		37
BROWN-YELLOW		19		RING		38
YELLOW-SLATE	20	45	CO LINE 20	TIP		39
SLATE-YELLOW		20		RING		40
VIOLET-BLUE	21	46	CO LINE 21	TIP		41
BLUE-VIOLET		21		RING		42
VIOLET-ORANGE	22	47	CO LINE 22	TIP		43
ORANGE-VIOLET		22		RING		44
VIOLET-GREEN	23	48	SPARE			45
GREEN-VIOLET		23				
VIOLET-BROWN	24	49	SPARE			47
BROWN-VIOLET		24				
VIOLET-SLATE	25	50	SPARE			49
SLATE-VIOLET		25				




Figure 2-2. Common Audible/Auxiliary Station Interface Wiring (Typical Connection)




Figure 2-3. PA Connections




Figure 2-4a. System Interconnection - Typical Connections




Figure 2-4b. System Interconnection - Typical Connections




Figure 2-5. Typical 6-Wire, Auxiliary-Pair Wiring

SYSTEM CHECKOUT

Initial Condition

The system operating features are set to a set of default conditions at initial power up. These conditions provide a basic operating system with a known set of parameters, and the system should be initially checked out with the default conditions in place. At anytime while the system is operating, default conditions can be reset from station port 10 or 11 per the instructions provided in Chapter 3.

Check Out

Check the KSU and telephone installation for proper operation by performing the following resistance and voltage measurements.

Resistance Check

Make the following resistance measurements at the station connector blocks under the following conditions.

- KSU AC power cord disconnected from electrical outlet.
 - Power interconnection cable connected between KSU and power supply.
 - KSU connected to station connector blocks.
 - Stations wired, and wiring punched down on blocks.
 - Bridging clips removed from blocks to isolate stations from KSU.
1. Measure the resistance of each installed station and wiring from the station side of the connector blocks. Resistance values will vary with cable length and station type but should be within the following limits.

MEASURED PAIR	MEASURED STATION RESISTANCE IN OHMS			
	22 LINE/ FEATURE	3 AND 8 LINE	SINGLE LINE	DSS/BLF CONSOLE
VOICE PAIR	40 - 150	40 - 150	40 - 150	0.3 - 100
DATA PAIR	0.3 - 100	40 - 150	0.3 - 100	0.3 - 100
AUX PAIR	OPEN	OPEN	N/A	N/A

2. Measure the resistance of the KSU and cables from the KSU side of the station connector blocks. Resistance values should be within the following limits.

MEASURED PAIR	MEASURED KSU RESISTANCE IN OHMS
VOICE PAIR	40 - 50
DATA PAIR	0.3 - 0.5

Voltage Check

Make the following voltage measurements at the station connector blocks under the following conditions

- Bridging clips installed
- AC power connected to the **KSU**

Measure the voltage across one voice line and one data line and then across the other voice line and the other data line for each even and odd station. The measured voltage must be as follows:

UNIT UNDER TEST	66M-xx BLOCK CONNECTION	METER LEAD POLARITY	MEASURED VOLTAGE
TYPICAL EVEN STATION Repeat for each even sta.	Voice 1	(+)	+33 +/- 5 VDC
	Data 3	(-)	
	Voice 2	(+)	+33 +/- 5 VDC
	Data 4	(-)	
TYPICAL ODD STATION Repeat for each odd sta.	Voice	(+)	-33 +/- 5 VDC
	Data 11	(-)	
	Voice 10	(+)	-33 +/- 5 VDC
	Data 12	(-)	

Variant readings can indicate a possible wiring, station, or KSU problem.

General Check

1. Check the red light emitting diode (LED) system status indicator. Be sure that it is on steady. If it is off or flashing, disconnect and reconnect the AC power plug. If the indicator is still not on steady, refer to the Failure Analysis Flow Chart found in Chapter 4.
2. Refer to the station User's Guide for operating information. Perform a general operational test of the system by exercising the system features from station port 10 or 11. Operational parameters are per the system default conditions as detailed in Chapter 3 until Class Of Service (COS) programming is performed.
3. Once the basic system is verified as operational, perform the COS programming.

CHAPTER 3
SYSTEM PROGRAMMING

GENERAL INFORMATION

- Class Of Service (COS) programming consists of the following major categories: General System COS, Toll Table Entry, Line COS, and Station COS.
- All COS programming commands must originate at a 22 Line/Feature Keypad installed at station port 10 or 11 and a companion DSS/BLF Console installed at console port 10a or 11a respectively. All COS programming commands will be accepted from any other stations connected to the system.
- Programming overlays are included with each system for use in identifying the keys required for COS programming. One overlay fits over the keys of the station installed at station port 10 or 11 and designates the A-field and B-field keys. The other overlay fits over the keys of the console installed at console port 10a or 11a and designates the C-field keys.
- System and line COS programming do not require that a sequential process be followed once the base level program entry mode has been established except where noted herein. Station COS programming does follow a sequential process.
- Prior to taking any programming action, determine the system, line and station COS conditions and all toll restriction requirements. Record this data on the programming reference tables included within the programming procedures.
- A set of COS values can be recorded on cassette tape from a programmed system and later re-loaded into the same system or into another system. This method of programming can be employed in lieu of using the step-by-step programming sequence.
- A complete or a partial printed record of the COS program values can be obtained with a serial data printer connected to the SMDR output lines of the KSU. Complete details concerning this procedure are included at the end of this chapter.

SPECIAL PROGRAMMING REQUIREMENTS
FOR SINGLE-LINE KEYSSETS

Several programming steps under COS programming must be observed for proper operation of a Single-Line **Keyset**.

- @When the system is strapped for key system configuration, the Single-Line **Keyset** is an intercom only station. It can be configured for private line only by programming the applicable station port for the prime line automatic feature. When the port is programmed with the prime line automatic feature, the Single-Line **Keyset** cannot be programmed with station speed dial numbers.
- When the system is strapped for the multifunction (hybrid) system configuration, to originate outside calls with a Single-Line **Keyset**, one or more lines must be programmed into a line group.
- In order to receive outside calls on a Single-Line **Keyset**, the call **must** be answered by an attendant using a multiline station and transferred to the single-line station. Otherwise, the Single-Line **Keyset** station port must be programmed to have the ringing line preference feature with ringing enabled on all desired lines. Alternately it can be programmed to have the prime line automatic feature with ringing enabled at the prime line.

BASE LEVEL PROGRAM ENTRY MODE

The first step in any COS programming sequence is to enter the base level programming mode from station port 10 or 11. Once in this mode, COS can be set as desired.

To enter base level:

1. Press the ITCM key. The dial tone will sound.
2. Press the following keys in sequence: * 7 4 6

Note that the dial tone stops and a tone burst sounds to indicate that the base level programming mode is entered.

3. Press the * key. The dial tone will return as a confirmation that the base level mode is active.
4. Proceed from this point to program the system, line, or station COS and the toll restriction tables.

CLASS OF SERVICE DEFAULT

The system can be defaulted to a standard class of service per the following procedure. The default conditions are listed at the beginning of each COS programming procedure and shaded on the programming reference charts.

1 Press ITCM * 7 4 6 *

2 Press program key C38

3 Press keypad key(s) to choose default settings

1 = system COS default 4 = pulse dialing - all lines

2 = line COS default 5 = tone dialing - all lines

3 = station COS default 6 = flexible key/function default

= One 80 column SMDR line & = Two 40 column SMDK lines

RECALL = Tape baud rate of 100

SAVE = Tape baud rate of 50

7051684 = master default (CAUTION: resets all values
and clears all stored memory - Do not perform
while system is in use)

4 Press * MONITOR

PROGRAMMING OVERLAYS







Several different telephone and console overlays are packed with the system. The overlay to be used is dependent upon the particular models of equipment connected to the programming station port (10 or 11) and the respective console port (10a or 11a). The programming overlays are illustrated in Figure 3-1. Full-scale copies of the overlays are also included at the end of this chapter. The full-scale copies can be removed and prepared for use if needed.

OVERLAY: 703804-274

OVERLAY: 703804-275

OVERLAY: 703500566

OVERLAY: 703500467



3-4

Figure 3-1. Programming Overlay Identification

SYSTEM COS PROGRAMMING PROCEDURE

SYSTEM DEFAULTS

- Recall/flash time = 2 seconds
- **Pause time** = 1 second
- Timed Hold recall time = 60 seconds
- Printer baud rate = 1200 baud, 7-bit data
- Port Assignments: All station ports= 22 Line/Feature **Keyset**
All console ports = 40-Key DSS/BLF Consoles
- Tape baud rate = 100
- Intercom signalling = voice first
- Central message Desk = not assigned
- Unanswered call transfer = 20 seconds
- Print length = 40 Col.

PROCEDURE

- 1 Press ITCM * 7 4 6 * (base level entry if not active)

- 2 Set recall/flash time
 - Press program key C34
 - Press keypad key for time
 - Press *

- 3 Set pause time.
 - Press program key C35
 - Press keypad key for time
 - Press *

- 4 Set timed hold recall time
 - Press program key C36
 - Press keypad key for time
 - Press *

- 5a Set the baud rate of printout
 - Press program key C39
 - Set baud rate with keypad
 - Press *

- 5b Set line length of printout
 - Press program key C38
 - Press # for one 80 col.
 - or-
 - Press 8 for two 40 col.
 - Press *

- 6 Choose intercom first signalling
 - Press RECALL for voice
 - press SAVE for tone
 - Press *

- 7 Specify central message desk
(one per system allowed)
 - Press #
 - Press keypad keys 010 - 041 to choose port 10 - 41
 - Press *

- 8 Set recall time for unanswered call transfer
 - Press program key C33
 - Press keypad keys for time
 - Press *

- 9 Specify station type for each station port
 - Press keypad keys 010 - 073 to identify station port 010 - 073
 - Press console key to specify station type
C18 = 32-Key Console without call announce
C19 = 32-Key Console with call announce
C20 = LCD Telephone
c22 = Single-Line **Keyset** (hotel telephone)
C25 = Single-Line **Keyset** (administrative telephone)
C23 = 3 and 8 Line **Keyset** C24 = 22 Line/Feature **Keyset**
 - Dial 3-digit code (100 - 399) to assign extension number (optional)
 - Press * and repeat steps for each active station port

NOTE: The step 9 action sets STATION COS for **IDed** port to the DEFAULT conditions for that type of station.

-continued

System COS programming procedure-continued

- 10 Specify console type for each console port
- Press console program key C10 to enable port selection
 - Press console program key to specify console port
 - C10 = console port 10a
 - C11 = console port 11a
 - Press console program key to specify console type
 - C10 = 70-Key console
 - C14 = 40-Key console
 - C15 = 32-Key console
 - Repeat port and console selection steps for all required ports
- 11 Select baud rate of tape data
- Press program key C38
 - Press RECALL for 100 baud
 - Press SAVE for 50 baud
 - Press *
- 12 Press *
- 13 Press MONITOR to exit or proceed to next COS

SYSTEM COS PROGRAMMING REFERENCE TABLE

@Shading denotes system default conditions

● Check off values chosen for system being programmed

BASE LEVEL (ITCM) (★) (7) (4) (6) (★)

2 (C34) RECALL/FLASH TIME

KEY	TIME	ENTRY
1	80 MSEC.	
2	300 MSEC.	
3	500 MSEC.	
4	600 MSEC.	
5	750 MSEC.	
6	875 MSEC.	
7	1.0 SEC.	
8	1.5 SEC.	
9	2.0 SEC.	
0	3.0 SEC.	

5A (C39) BAUD RATE FOR COS AND SMDR DATA

KEY	DATA SPEED	ENTRY
1	110 BAUD, 7 BITS	
2	150 BAUD, 7 BITS	
3	300 BAUD, 7 BITS	
4	600 BAUD, 7 BITS	
5	1200 BAUD, 7 BITS	
6	2400 BAUD, 7 BITS	
7	3600 BAUD, 7 BITS	
8	4800 BAUD, 7 BITS	
9	9600 BAUD, 7 BITS	
0	19200 BAUD, 7 BITS	

3 (C35) PAUSE TIME

KEY	TIME	ENTRY
1	.5 SEC.	
2	1.0 SEC.	
3	1.5 SEC.	
4	2.0 SEC.	
5	3.0 SEC.	
6	5.0 SEC.	
7	7.5 SEC.	
8	10.0 SEC.	
9	15.0 SEC.	
0	20.0 SEC.	

5B (C38) PRINT OUT LINE LENGTH

(#) 80	COLUMN 1 LINE
(8) 40	COLUMN 2 LINES

6 INTERCOM FIRST CHOICE SIGNALLING

(RECALL) VOICE	
(SAVE) TONE	

4 (C36) HOLD RECALL TIME

KEY	TIME	ENTRY
1	30 SEC.	
2	60 SEC.	
3	90 SEC.	
4	120 SEC.	
5	180 SEC.	
6	240 SEC.	
7	300 SEC.	
8	360 SEC.	
9	420 SEC.	
0	DISABLED	

Note: 0 program selection (disabled) enables exclusive hold condition (when set at station) to place line on hold that cannot be released at any other station.

7 (#) CENTRAL MESSAGE DESK

○ ○ ○	STATION PORT ASSIGNED.
(*)	NONE ASSIGNED

8 (C33) RECALL TIME UNANSWERED CALL TRANSFER

KEY	TIME	ENTRY
1	10 SEC.	
2	20 SEC.	
3	25 SEC.	
4	30 SEC.	
5	45 SEC.	
6	60 SEC.	
7	90 SEC.	
8	120 SEC.	
9	180 SEC.	
0	240 SEC.	

9

PORT ID	STATION TYPE		DIALING EXTENSION	LOCATION OF STATION
	C18 - 32-KEY CON. W/O C.A.			
	C19 - 32-KEY CON. W.C.A.			
	C20 - LCD PHONE			
	C22 - S-L (HOTEL)			
	C23 - 3 AND 8 LINE			
	C25 - S-L (ADMIN.)			
010			110	
011			111	
012			112	
013			113	
014			114	
015			115	
016			116	
017			117	
016			118	
019			119	
020			120	
021			121	
022			122	
023			123	
024			124	
025			125	
026			126	
027			127	
028			128	
029			129	
030			130	
031			131	
032			132	
033			133	
034			134	
035			135	
036			136	
037			137	
038			138	
039			139	
040			140	
041			141	

10

C10 SPECIFY CONSOLE TYPE FOR EACH CONSOLE PORT	
CHOOSE PORT	CHOOSE CONSOLE TYPE
C10 PORT 10a	C10 70-KEY CONSOLE
C11 PORT 11a	C14 40-KEY CONSOLE
	C15 32-KEY CONSOLE

11

C38 BAUD RATE OF TAPE DATA		
KEY	BAUD RATE	ENTRY
RECALL	100	
SAVE	50	

TOLL RESTRICTION PROGRAMMING

In order for toll restriction to take effect, the following three-fold process must occur.

- One or more toll tables must be entered.
- Toll tables must be assigned to all appropriate lines.
- Toll tables must be assigned to all appropriate stations.

Only the toll table(s) which are entered and assigned to both a line and a station using that line will invoke any toll restriction.

TABLE ENTRY PROCEDURE

1. Determine the types of dialing restrictions which must be imposed on the system. Typically, this includes access codes which result in toll charges, and certain local numbers as desired.
2. If the restricted dialing codes will be imposed consistently on most or all stations in the system, list them on one or two tables. If wide variation in the dialing restrictions is planned, spread the listing out across several tables.
3. Strategically group the listings on the tables so that a list of restrictions can be applied to a particular station or group of stations.
4. Designate each table as a DENY table or as an ALLOW table. The numbers entered in a DENY table are prevented from being dialed. ALLOW tables take precedence over DENY tables. Therefore, an entry in an ALLOW table will provide an explicit exception to an entry in a DENY table. *Note that the system a/ways permits the dialing of any number not explicitly denied. Also, system speed dial numbers will not be toll restricted unless specified by station COS programming.*
 - Example A: Provide a simple and broad toll restriction format by creating a DENY table with two entries: Entry (1) = 1 Entry (2) = 0. This format prevents all long distance and operator calls.
 - Example B: Prevent the dialing of all numbers within the (804) area code, while allowing the dialing of one specific number within that area code, by entering 1804 in a DENY table and 18049782200 in an ALLOW table. Alternately, allow all numbers in the 978 exchange by entering 1804978 in an ALLOW table.
5. Press the # key in place of a particular digit to condense a range of numbers into one entry. The # character is a "match-anything" digit, and can be included in an entry in either a DENY table or an ALLOW table.
 - Example A: If 357, 377, 387, and 397 dialing is to be prohibited, list one entry of 3#7 on a DENY table to cover them all.
 - Example B: Since area codes typically have a 1 or a 0 as a middle digit, prevent long distance calls to those area codes by entering 1 #1# and 1#0# in a DENY table.
6. Since it is important that emergency numbers never be restricted, always create an ALLOW table with entries of 911 and 1911 to override any DENY tables that have been created.
7. If the system is installed behind a PBX, include an access code as part of every table entry.
8. Once these tables are completely filled out, enter the restriction planning tables on the line, and station programming reference charts to record the planned toll restrictions for the system.

TOLL RESTRICTION PROGRAMMING PROCEDURE

- 1 Press ITCM * 7 4 6 * (base level entry if not active)
- 2 Press program key C37 (enter toll program mode)
- 3 Press console key C10 - C25 to select table number (1 - 16)

KEY	C10	C11	C12	C13	C14	C15	C16	C17
TABLE	1	2	3	4	5	6	7	8
KEY	C18	C19	C20	C21	C22	C23	C24	C25
TABLE	9	10	11	12	13	14	15	16

- 4 Select table type
 - Deny - press program key C38
 - Allow - press program key C39
- 5 Select table entry
 - Press program key A1 - A4 to select entry 1 - 4
- 6 Dial number (16 digits max.) (Press # for "match anything" digit)
- 6 Repeat steps 3 through 7 until all tables are programmed
- 9 Press *
- 10 Press MONITOR to exit or proceed to next COS programming step.

KEY	A1	A2	A3	A4
ENTRY	1	2	3	4

TOLL RESTRICTION PROGRAMMING REFERENCE TABLES

RESTRICTION TABLE 1																
TYPE: ALLOW _____ DENY _____																
ENTRY	ENTRY NUMBER (16 MAXIMUM)															
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
1																
2																
3																
4																
TABLE ASSIGNMENT: LINES _____ STATIONS _____																

RESTRICTION TABLE 2																
TYPE: ALLOW _____ DENY _____																
ENTRY	ENTRY NUMBER (16 MAXIMUM)															
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
1																
2																
3																
4																
TABLE ASSIGNMENT: LINES _____ STATIONS _____																

RESTRICTION TABLE 3																
TYPE: ALLOW _____ DENY _____																
ENTRY	ENTRY NUMBER (16 MAXIMUM)															
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
1																
2																
3																
4																
TABLE ASSIGNMENT: LINES _____ STATIONS _____																

RESTRICTION TABLE 4																
TYPE: ALLOW _____ DENY _____																
ENTRY	ENTRY NUMBER (16 MAXIMUM)															
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
1																
2																
3																
4																
TABLE ASSIGNMENT: LINES _____ STATIONS _____																

RESTRICTION TABLE 5																
TYPE: ALLOW _____ DENY _____																
ENTRY	ENTRY NUMBER (16 MAXIMUM)															
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
1																
2																
3																
4																
TABLE ASSIGNMENT: LINES _____ STATIONS _____																

RESTRICTION TABLE 6																
TYPE: ALLOW _____ DENY _____																
ENTRY	ENTRY NUMBER (16 MAXIMUM)															
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
1																
2																
3																
4																
TABLE ASSIGNMENT: LINES _____ STATIONS _____																

RESTRICTION TABLE 7																
TYPE: ALLOW _____ DENY _____																
ENTRY	ENTRY NUMBER (16 MAXIMUM)															
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
1																
2																
3																
4																
TABLE ASSIGNMENT: LINES _____ STATIONS _____																

RESTRICTION TABLE 6																
TYPE: ALLOW _____ DENY _____																
ENTRY	ENTRY NUMBER (16 MAXIMUM)															
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
1																
2																
3																
4																
TABLE ASSIGNMENT: LINES _____ STATIONS _____																

RESTRICTION TABLE 9																
TYPE: ALLOW _____ DENY _____																
ENTRY	ENTRY NUMBER (16 MAXIMUM)															
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
1																
2																
3																
4																
TABLE ASSIGNMENT: LINES _____ STATIONS _____																

RESTRICTION TABLE 10																
TYPE: ALLOW _____ DENY _____																
ENTRY	ENTRY NUMBER (16 MAXIMUM)															
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
1																
2																
3																
4																
TABLE ASSIGNMENT: LINES _____ STATIONS _____																

RESTRICTION TABLE 11																
TYPE: ALLOW _____ DENY _____																
ENTRY	ENTRY NUMBER (16 MAXIMUM)															
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
1																
2																
3																
4																
TABLE ASSIGNMENT: LINES _____ STATIONS _____																

RESTRICTION TABLE 12																
TYPE: ALLOW _____ DENY _____																
ENTRY	ENTRY NUMBER (16 MAXIMUM)															
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
1																
2																
3																
4																
TABLE ASSIGNMENT: LINES _____ STATIONS _____																

RESTRICTION TABLE 13																
TYPE: ALLOW _____ DENY _____																
ENTRY	ENTRY NUMBER (16 MAXIMUM)															
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
1																
2																
3																
4																
TABLE ASSIGNMENT: LINES _____ STATIONS _____																

RESTRICTION TABLE 14																
TYPE: ALLOW _____ DENY _____																
ENTRY	ENTRY NUMBER (16 MAXIMUM)															
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
1																
2																
3																
4																
TABLE ASSIGNMENT: LINES _____ STATIONS _____																

RESTRICTION TABLE 15																
TYPE: ALLOW _____ DENY _____																
ENTRY	ENTRY NUMBER (16 MAXIMUM)															
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
1																
2																
3																
4																
TABLE ASSIGNMENT: LINES _____ STATIONS _____																

RESTRICTION TABLE 16																
TYPE: ALLOW _____ DENY _____																
ENTRY	ENTRY NUMBER (16 MAXIMUM)															
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
1																
2																
3																
4																
TABLE ASSIGNMENT: LINES _____ STATIONS _____																

LINE COS PROGRAMMING

 LINE DEFAULTS

- Line type = TELCO
 - Dial Mode = DTMF
 - Toll Tables = none assigned
 - Line groups = none assigned
 - Privacy status = private
 - Abandoned Hold Timeout = 50 msec.
-

PROCEDURE

1 Press ITCM * 7 4 6 * (base level entry if not now active)

2 Select line to be programmed.
 Perform all applicable steps.
 ● Press program key per chart below to choose line 1 - 22

LINE	KEY	LINE	KEY	LINE	KEY
1	B1	9	A7	17	A3
2	B2	10	A14	18	A10
3	B3	11	A6	19	A2
4	B4	12	A13	20	A9
5	B5	13	A5	21	A1
6	B6	14	A12	22	A8
7	B7	15	A4		
8	B8	16	A11		

3 Select line type
 Press program key:
 ● Disabled = key C38
 ● Auxiliary = key C39
 ● CO/PBX = key C40

5 Select dialing mode
 Press program key:
 ● Pulse/tone = key C26
 ● Tone only = key C27

4 Select line group
 Press program key:
 (multifunction config. only)
 ● None = key C41
 ● Gp 1 = key C34
 ● Gp 2 = key C35
 ● Gp 3 = key C36
 ● Gp 4 = key C37

7 Assign toll tables
 Press program key(s)
 ● Clear all = key C33
 ● Assign = keys C10 - C25

TABLE	KEY	TABLE	KEY
1	C10	9	C18
2	C11	10	C19
3	C12	11	C20
4	C13	12	C21
5	C14	13	C22
6	C15	14	C23
7	C16	15	C24
8	C17	16	C25

6 Select privacy mode
 Press program key:
 ● Private = key C28
 ● Non-private = key C29

8 Set abandoned hold timeout period
 Press program key
 ● 300 msec. = key C30
 ● 50 msec. = key 31

9 Repeat steps 2 - 8
 for each line

10 Press *


11 Press MONITOR to exit or proceed to next COS programming step.

LINE COS PROGRAMMING REFERENCE TABLE

- Shading denotes line default conditions.
- Check off or enter the values chosen for the lines being programmed.

	SELECT LINE FEATURE	B1	B2	B3	B4	B5	B6	B7	B8	A7	A14	A6	A13	A5	A12	A4	A11	A3	A10	A2	A9	A1	A8
		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
3	SELECT LINE	<input type="checkbox"/> C38	DISABLED																				
	LINE	<input type="checkbox"/> C39	AUXILIARY																				
		<input checked="" type="checkbox"/> C40	CO/PBX																				
4	GROUPS MULTIFUNC. TION SYS— TEMS ONLY)	<input checked="" type="checkbox"/> C24	GROUP 1																				
		<input checked="" type="checkbox"/> C25	GROUP 2																				
		<input checked="" type="checkbox"/> C36	GROUP 3																				
		<input checked="" type="checkbox"/> C37	GROUP 4																				
		<input checked="" type="checkbox"/> C41	NONE ASSIGNED																				
5	DIAL MODE	<input checked="" type="checkbox"/> C26	PULSE/TONE																				
		<input checked="" type="checkbox"/> C27	TONE ONLY																				
6	PRIVACY MODE	<input checked="" type="checkbox"/> C28	NON-PRIVATE																				
		<input checked="" type="checkbox"/> C29	PRIVATE																				
7	TOLL RESTRICTION TABLE ASSIGNMENT	<input checked="" type="checkbox"/> C10	1																				
		<input checked="" type="checkbox"/> C11	2																				
		<input checked="" type="checkbox"/> C12	3																				
		<input checked="" type="checkbox"/> C13	4																				
		<input checked="" type="checkbox"/> C14	5																				
		<input checked="" type="checkbox"/> C15	6																				
		<input checked="" type="checkbox"/> C16	7																				
		<input checked="" type="checkbox"/> C17	8																				
		<input checked="" type="checkbox"/> C18	9																				
		<input checked="" type="checkbox"/> C19	10																				
		<input checked="" type="checkbox"/> C20	11																				
		<input checked="" type="checkbox"/> C21	12																				
		<input checked="" type="checkbox"/> C22	13																				
		<input checked="" type="checkbox"/> C23	14																				
		<input checked="" type="checkbox"/> C24	15																				
		<input checked="" type="checkbox"/> C25	16																				
			<input checked="" type="checkbox"/> C25	PRIVATE																			
	ABANDONED	<input checked="" type="checkbox"/> C30	300 MSEC																				
	HOLD TIMEOUT	<input checked="" type="checkbox"/> C31	99 MSEC																				

CO/PBX NUMBERS
AND STATION
ASSIGNMENTS



* Power Fail Lines (1, 2, 3, and 4)
 ** A-Lead Control Lines (13, 14, 15, and 16)

STATION COS PROGRAMMING

STATION DEFAULTS

- PA port = disabled
- Ringing line preference =disabled
- Personal ringing tone = tone 1
- Toll tables = none assigned
- Line access denied = none
- Idle line preference = none
- All-call receive = enabled
- All-call originate = enabled
- Zone page receive = disabled
- Zone page originate = disabled
- Automatic hold = disabled
- System speed dial toll restric. = disabled
- Voice announce block = disable-
- Privacy status = private
- Executive override = disabled
- Prime line/group = none
- Single Line Keyset accesses intercom
- Ringing assignment = all lines ring on stations 10, 17, 39, and 41
- Origination denied = none
- Night transfer = all lines ring on stations 10, 17, 39 and 41
- Reserved intercom link = none
- Message originate = disabled
- Line/key assignment:
 - 3 and 8 Line Keyset
 - B-Field keys (B1=B8) = lines 1=8
 - 22 Line/Feature Keyset
 - A-Field keys = lines 9 = 22
 - B-Field keys = lines 1 = 8

PROCEDURE

- Perform all steps in sequence.
 - Skip those steps not required.
- 1 Press ITCM * 7 4 6 * (base level entry)
 - 2 Press program key C41 (program entry)
 - 3 Specify station to be programmed and perform applicable steps
 - Press keypad keys 010-041 to select station port 010 - 041
 - Action defaults following settings:
 - PA port
 - Prime line
 - Voice blocking
 - Executive override
 - Message wait-originate
 - Automatic hold
 - System speed dial toll rest.
 - Ringing line preference
 - 4 Enable PA port (DO NOT PROCEED BEYOND THIS STEP - IF PERFORMED)
 - Press program key C10
 - Return to step 2
 - 5 Block voice announced intercom calls
 - Press C11
 - 7 Enable toll table restriction on system speed dial numbers
 - Press program key C13
 - 6 Enable executive override
 - Press program key C12

- continued

Station COS - continued

- 8** Choose personal ringing tones
(22 Line/Feature **Keysets**)
- TONE 1 = program key C14
 - . TONE 2 = program key C15
 - TONE 3 = program key C16
 - . TONE 4 = program key C17

- 9** Set automatic hold
- Press program key **C26**

- 10** Enable message wait originate
- Press program key **C27**

- 11** Select prime line
or prime group
- Press program key per chart to select line 1 - 22
or press ITCM to select intercom line
 - Press program key per chart to choose prime group

LINE	KEY	LINE	KEY	LINE	KEY	GROUP	KEY
1	B1	9	A7	17	A3	1	C34
2	B2	10	A14	18	A10	2	C35
3	B3	11	A6	19	A2	3	C36
4	B4	12	A13	20	A9	4	C37
5	B5	13	A5	21	A1		
6	B6	14	A12	22	A8		
7	B7	15	A4				
8	B8	16	A11				

- 12** Set ringing line preference
- Press program key **C40**

- 13** Select ringing assignments
RINGING
- Press console key C18
(clears previous settings)
 - Press program key(s) per chart in step 11
- DELAYED RINGING
- Press console key C19
(clears previous settings)
 - Press program key(s) per chart in step 11.

- 14** Select Night Transfer (ringing)
- Press console key **C20**
(clears previous settings)
 - Press program key(s) per chart in step 11.

- 15** Select automatic privacy release
- Press console key **C21**
(clears previous settings)
 - Press program key(s) per chart in step 11.

- 16** Select access denied
- Press console key **C22**
(clears previous settings)
 - Press program key(s) per chart in step 11.

- 17** Select call origination denied
- Press console key **C23**
(clears previous settings)
 - Press program key(s) per chart in step 11.

- 18** Select idle line preference
- Press console key **C24**
(clears previous settings)
 - Press program key(s) per chart in step 11.

-continued

Station COS - continued

- 19a** Enter toll table assignment mode
 To clear all toll tables assigned
 ● Press program key C25
- 19b** Specify toll tables
 ● Press program key C10-25

KEY	C10	C11	C12	C13	C14	C15	C16	C17
TABLE	1	2	3	4	5	6	7	8
KEY	C18	C19	C20	C21	C22	C23	C24	C25
TABLE	9	10	11	12	13	14	15	16

- 20** Reserve intercom link
- Press #
 - Press keypad key 1-7 to reserve link 1-7
 - or-
 - Press 0 key for no reserved link
 - Press console key C18 to continue with next step

- 21** Select all-call and/or zone paging
- Press #
 - Press RECALL to disable all paging assignments (if desired)

ALL-CALL

- Press program key A4 to originate
- Press program key A8 to receive
- Press console key C18 to continue with next program step

ZONES A, B, AND C

- Press #
- Press program keys A1-A3 and A5-A7 to enable zones

	ORIGINATE			RECEIVE		
KEY	A1	A2	A3	A5	A6	A7
ZONE	A	B	C	A	B	C

- Press console key C10 to continue with next program step

- continued

Station COS - continued

22 Specify flexible key/function assignment
(non-square configuration), if required.

3 AND 8 LINE KEYSET

- Press program key C39
- Press program key C34 - C41 to choose line keys 1 - 8
- Fast tone bursts will $\diamond \square \blacklozenge \blacksquare$
- Press program key per step 11 chart to assign lines 1 - 22
-or-
- * Press RECALL key to disable line appearance
- Tone bursts stop
- Repeat for each line assigned

22 LINE/FEATURE KEYSET

- Press program key C39

Assign Lines To Keys

- Press key **to be** assigned (A or B field) - Fast tone bursts sound
- Press program key per step 11 chart to assign lines 1 - 22
- Tone bursts stop
- Repeat for all keys requiring line appearance

Disable Line Appearance At Keys (clears any prior assignment)

- Press key **to be** denied appearance - Fast tone bursts sound
- Press **RECALL** key - tone bursts stop
- Repeat procedure for all required key locations

Assign DSS To Keys

- Press key **to be** assigned (A or B field) - Fast tone bursts sound
- Press keypad keys 010 - 041 to choose station ports 10 - 41
- Tone bursts stop
- Repeat for all keys requiring DSS assignment

Assign Autodial To Keys (clears any prior assignment)

- Press key **to be** assigned (A or B field) - Fast tone bursts sound
- Press **RECALL** key - tone bursts stop
- Repeat procedure as required for all **autodial** keys

Assign Dynamic Loop Keys (clears any prior assignment)

- Press key **B1, B2, or B3** - Fast tone bursts sound
- Press **RECALL** key - tone bursts stop
- Repeat for B2 and B3 if required

- continued

Station COS - continued

23 Press *

24a Choose next station port for programming

- Press program key **c41**
- Press keypad keys **010 - 041**

-or-

24b Block program a group of stations with same COS as previously programmed station

- Press **HOLD**
- Press keypad **keys** to specify model station
- Press keypad **keys** to specify first station in **block**
- Press keypad **keys** to specify last station in **block**.

Note: Flexible key/function assignments for station port 10 or 11 cannot be changed by **block** programming.

25 If block programming of step **24b** is not performed, repeat steps 5 through 24a for each station in system.

26 Press * **MONITOR** to exit programming.

- end

STATION COS PROGRAMMING REFERENCE TABLE (Copy This Page To Provide Additional Reference Sheets)

- Shading denotes line default conditions.
- Check off or enter the values chosen for the lines being programmed.

BASE LEVEL **(ITCM)** **(*)** **(7)** **(4)** **(6)** **(*)**
 STATION PROGRAMMING MODE **(C4)**

STATION ID (REF. SYSTEM COS CHART)	
PORT	
STA. TYPE	
EXTENTION	
LOCATION	

4

PA PORT	DISABLED
(C10)	ENABLED

	ENABLED	DISABLED
5 (C11) VOICE BLOCK		
6 (C12) EXECUTIVE OVERRIDE		
7 (C13) SYS. SPEED TOLL		
9 (C28) AUTOMATIC HOLD		
10 (C27) MESSAGE WAIT-ORIG.		

8

PERSONAL RINGING			
ZONE 1	ZONE 2	ZONE 3	ZONE 4
(C14)	(C15)	(C16)	(C17)

11

PRIME LINE-AUTOMATIC																							
NONE	ITCM	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
	(ITCM)	(B1)	(B2)	(B3)	(B4)	(B5)	(B6)	(B7)	(B8)	(A7)	(A14)	(A6)	(A13)	(A5)	(A12)	(A4)	(A11)	(A3)	(A10)	(A2)	(A9)	(A1)	(A8)
GROUP																							
		1	2	3	4																		
		(C34)	(C35)	(C36)	(C37)																		

12

RINGING LINE PREFERENCE	(C40)	ENABLED
-------------------------	--------------	---------

13-14

RINGING ASSIGNMENT FOR LINES	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	
(C18) RINGING																							
(C19) DELAYED RINGING																							
(C20) NIGHT RINGING																							
DEFAULTS TO RINGING ON ALL LINES FOR STATIONS 10, 17, 39, AND 41.																							

LINE SELECT KEYS			
1	B1	12	A13
2	B2	13	A5
3	B3	14	A12
4	B4	15	A4
5	B5	16	A11
6	B6	17	A3
7	B7	18	A10
8	B8	19	A2
9	A7	20	A9
10	A14	21	A1
11	A6	22	A8

15-18

	NONE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
(C21) AUTO PRIVACY REL.																							
(C22) ACCESS DENIED																							
(C23) ORIG. DENIED																							
(C24) IDLE LINE PEF.																							

19

(C25) TOLL TABLE ASSIGNMENT																
NONE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
	(C10)	(C11)	(C12)	(C13)	(C14)	(C15)	(C16)	(C17)	(C18)	(C19)	(C20)	(C21)	(C22)	(C23)	(C24)	(C25)

21

ALL-CALL AND ZONE PAGING				
	ZONE A	ZONE B	ZONE C	ALL-CALL
RECEIVE	(A5)	(A6)	(A7)	(A8)
ORIGINATE	(A1)	(A2)	(A3)	(A4)
(RECALL) CLEARED				
PRESS (C18) TO CONTINUE				

20

(#) RESERVE INTERCOM LINKS							
NONE	1	2	3	4	5	6	7
(0)	1	2	3	4	5	6	7
PRESS (C18) TO CONTINUE							

22

(C39) KEY MAPPING--3 AND 8 LINE KEY SET								
MAPPED KEY	(C34)	(C35)	(C36)	(C37)	(C38)	(C39)	(C40)	(C41)
LINE ASSIGNED								
DISABLED (RECALL)								

(C39) KEY MAPPING--22 LINE/FEATURE KEYS																								
	MAPPED KEY	A1	A2	A3	A4	A5	A6	A7	A8	A9	A10	A11	A12	A13	A14	B1	B2	B3	B4	B5	B6	B7	B8	
SELECTION CHART KEY	LINE ASSIGNED																							
	DSS STA. ASSIGNED																							
	AUTO DIAL ASSIGNED																							
RECALL	UNASSIGNED																							
	DYNAMIC LOCK KEY																							

LINE SELECT KEYS			
1	B1	12	A13
2	B2	13	A5
3	B3	14	A12
4	B4	15	A4
5	B5	16	A11
6	B6	17	A3
7	B7	18	A10
8	B8	19	A2
9	A7	20	A9
10	A14	21	A1
11	A6	22	A8

COS AND SMDR PRINTOUT

COS PRINTOUT

When a data printer is connected to the system, it can be commanded, from station port 10 or 11, to print the class of service (COS) programming configuration. Partial or complete printouts can be obtained. When the printer is being used to obtain a COS printout, the Station Message Detail Recording (SMDK) function is temporarily halted. SMDR data collection is continued by the system during a COS printout operation; however, if more than two calls are logged for any one line, call records may be lost.

1 Press ITCM * 7 4 6 * (base level entry if not active)

2 Press program key C39

3 Choose desired printout

- Press program key per chart

PRINTOUT	PROGRAM KEY
All COS	C37
System COS	C38
Line COS	C39
Toll Tables	C40
All station COS	c41
One Station COS	c34 plus 010 ~ 041 to choose station port


4 COS printout begins immediately

- To abort printout, press program key C40.

5 Press * MONITOR (ends procedure)

SMDR PRINTOUT

The SMDR printout data is provided automatically as it is generated. No intervention is required to obtain the printout. The data is formatted as shown in Figure 3-2. Either an 80-column or a 40-column printout line can be selected through the SYSTEM COS programming.



NOTES

1. CARRIAGE RETURN AND LINE FEED IMMEDIATELY FOLLOW LAST PRINTED CHARACTER ON EACH LINE. ALSO SEE NOTE 2.
2. ILLUSTRATED PRINTOUT IS 40 COLUMN, TWO-LINE FORMAT. FOR 80 COLUMN ONE-LINE PRINTOUT FORMAT, CARRIAGE RETURN AND LINE FEED CHARACTERS AT END OF LINE 1 ARE REPLACED BY TWO SPACES FOLLOWED BY ENTIRE CONTENTS OF LINE 2.
3. OUTGOING CALL MUST BE OFF HOOK FOR 20 SECONDS MINIMUM OR NO RECORDING OCCURS.

PRINTOUT EXAMPLES	
UNANSWERED INCOMING CALL	1 12/05/86 16:51 NOANS 0.6
ANSWERED INCOMING CALL	16 1 12/05/86 16:52 1.6 0.2
ANSWERED INCOMING CALL (WITH CALLER ID ADDED BY STATION DURING CALL)	24 1 12/05/86 16:53 1.2 0.2 "1234
OUTGOING CALL (LOCAL)	16 2 12/05/86 16:58 2.0 9782200
OUTGOING CALL (WITH ACCOUNT CODES)	2 4 2 12/05/86 17:01 .5 11233456789*0#*7412580#9631*#
AC POWER FAILURE AND RESTORATION	OFF TIME . * 12/05/86 17:03 ** 12/05/86 17:08

Figure 3-2. SMDK Printout Details

CASSETTE TAPE RECORD OF COS VALUES

- Connect audio cassette tape recorder to music interface on side of KSU.
- DO not perform other programming action while tape system is active.
- Program baud rate of tape data to be 100 or 50 baud as desired. (See System COS programming discussion for details.)
- If the system includes a data printer, appropriate response messages will be printed during the recording and loading of COS data.

RECORDING COS DATA TO TAPE

To record currently stored COS program values on cassette tape for later use, proceed as follows:

1. Install blank cassette tape, and prepare recorder for recording.
2. Cause recorder to begin recording blank cassette tape from beginning.
3. Press **ITCM * 7 4 6 * ITCM**
4. Press appropriate program key to start recording process.
 - c37 = COS FEATURES
 - c34 = ALL SPEED DIALS
 - c35 = AUTODIALS (**STA** 010 - 025)
 - C36 = AUTODIALS (STA 026 - 041)
5. To abort procedure (if required),
 - Press **ITCM * 7 4 6 * ITCM**
 - Press program key C41.

COS recording requires approximately 12 minutes. Station port 10 or 11 will ring when recording is complete.

COMPARING RECORDED DATA (Requires Data Printer)

To compare recorded values with system values,

- Rewind cassette tape, and prepare recorder for playback.
- Press **ITCM * 7 4 6 * ITCM**
- Press program key **C38**
- Start tape playback
- Printer will print status as follows:
 - COMPARE TAPE TO COS DATA
 - COMPARE TAPE COMPLETE
 - COMPARE TAPE DATA ERROR

VERIFING TAPE DATA (Requires Data Printer)

To verify previously recorded cassette tape,

- Rewind pre-recorded cassette tape, and prepare recorder for play-back.
- Press ITCM * 7 4 6 * ITCM
- Start tape playback
- Press program key **C39**
- Printer will print status as follows:
VERIFY COS DATA TAPE
VERIFY TAPE **DATA** COMPLETE
VERIFY TAPE DATA ERROR

LOADING COS DATA FROM TAPE

To load previously recorded COS program values into system to replace current program values, proceed as follows:

1. Install pre-recorded cassette tape, and prepare recorder for playback
2. Press ITCM * 7 4 6 * ITCM
3. To load COS features,
 - Press HOLD
 - or-
 - To load memory dialing numbers,
 - Press RECALL
4. Start tape playback.
5. To abort the procedure (if required),
 - Press ITCM * 7 4 6 * ITCM
 - Press program key **C41**.

COS loading requires approximately 10 minutes. Station port 10 or 11 will ring when loading is complete.

SYSTEM CLOCK INFORMATION

All clock setting and adjustment **must** be performed from station port 10 or 11.

SETTING THE CLOCK

1. Press ITCM , then dial * #
2. Dial the clock date with the key pad keys

YEAR	MONTH	DAY	HOUR	MINUTE
------	-------	-----	------	--------

NOTE

Values less than 10 must be dialed as OX.
Hours must be expressed in the 24-hour format.

3. If the SMDR printer is installed and operating, the clock date will be printed as follows.

** 01/08/86 16:00 (Example)

4. Reset the minutes setting, if necessary, as follows:
 - a. Repeat step 1.
 - b. Dial the new minutes digits, and press the # key.
 - c. A new clock date printing will **occur**.
5. To obtain a printing of the current clock date, press ITCM * # #

Printing will occur automatically once each 24-hour period.

** MO/DY/YR 00:00 (current date and 00:00 hours)

POWER INTERRUPTION

The system clock will continue to run for at least 30 minutes after AC power has been removed from the system. If power is restored within the 30-minute backup period, the following printing sequence will occur:

LAST VALID CLOCK = MO/DY/YR HR:MN (time of power outage)
MO/DY/YR HR:MN (time of power return)

If power is not restored within the backup period, the following printing sequence will occur when the power is restored.

CLOCK NOT VALID
12/01/86 00:00 (default clock date)

The clock will begin running from the default date. It must be reset to the current date per the instructions above.

SYSTEM SPEED DIAL PROGRAMMING

Fifty (50) **system** speed dial numbers can be stored from station port 10 or 11 for **use at all stations in the system.** System speed dial numbers will not be toll restricted unless specified by station COS programming.

- Press ITCM *
- Press SAVE
- Dial storage location (10 - 59)
- Choose line or group preselection (multifunction (hybrid) **system** only)
 - Dial 1 - 4 for group
 - or-
 - @ Press a line **key** for line
 - Note: Key-to-line assignment per programming arrangement. Refer to station COS programming reference chart for station port 10 key-to-line assignments.
 - or-
 - Dial 0 for no group or line preselection
- Dial speed dial number (up to 32 digits)
 - Dial 1 - 0, #, and *
 - Press HOLD to store pause if required
 - Press RECALL to store flash if required
- Press SAVE and repeat procedure for each number.
- Press MONITOR to end procedure

SYSTEM SPEED DIAL INDEX

*10	*27	*45
*11 I	*28	*46
*12	*29	*47
*13	*30	*48
*14	*31	*49
*15 I	*32	*50
*16	*33	*51
*17 I	*34	*52
*18	*35	*53
*19	*36	*54
*20	*37	*55
*21	*38	*56
*22	*39	*57
*23	*40	*58
*24	*41	*59
*25	*43	
*26	*44	




Figure 3-3a. Programming Reference Chart





Figure 3-3b. Programming Reference Chart

STATION 10 - PROGRAMMING OVERLAY

- Cut out along border.
- Cut out shaded openings.
- Fit over station faceplate.



STATION 10 - PROGRAMMING OVERLAY

- Cut out along border.
- Cut out shaded openings.
- Fit over station faceplate.


A1		A 8
A 2	703500-566	A 9
A 3	PROGRAMMING	A10
	OVERLAY	
A 4		A11
A 5		A12
A 6		A13
A 7		A14
0 7		B8
B 5		B 6
B3		B4
B1		B2

CONSOLE - PROGRAMMING OVERLAY


- Cut out along border.
- Cut out shaded openings.
- Fit over console faceplate.

703500-567
PROGRAMMING OVERLAY


C70 C71 C72 C73 C74 C75 C76 C77 C78 C79




C60 C61 C62 C63 C64 C65 C66 C67 C68 C69




C50 C51 C52 C53 C54 C55 C56 C57 C58 C59




C40 C41 C42 C43 C44 C45 C46 C47 C48 C49




C30 C31 C32 C33 C34 C35 C36 C37 C38 C39



C20 C21 C22 C23 C24 C25 C26 C27 C28 C29



C10 C11 C12 C13 C14 C15 C16 C17 C18 C19



993 5353


CONSOLE - PROGRAMMING OVERLAY

- Cut out along border.
- Cut out shaded openings.
- Fit over console faceplate.


EXECUTECH PROGRAMMING OVERLAY

703804-275


C42 C43 C44 C45 C46 C47 C48 C49




C34 C35 C36 C37 C38 C39 C40 C41




C26 C27 C28 C29 C30 C31 C32 C33



C18 C19 C20 C21 C22 C23 C24 C25



C10 C11 C12 C13 C14 C15 C16 C17



12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29

CHAPTER 4
MAINTENANCE

TECHNICAL ASSISTANCE AND REPAIR SERVICE

Technical Assistance

Should you experience difficulty with installation, checkout, or programming, and have made an attempt to isolate the problem using information provided herein; or should you encounter problems at a later date which cannot be resolved by referring to this manual, call the Comdial Technical Service staff. They can be reached at 800-431-4345 (in Virginia: 800-654-3345) between the hours of 8:00 AM and 8:00 PM Eastern time, Monday through Friday.

When calling for technical assistance, you should be at the job site and you should have in your possession, as a minimum, an accurate volt-ohm meter and a copy of this manual.

Repair Service

If your KSU or an individual station needs repair, subsequent to the warranty period, it may be returned to Comdial. Comdial will, at their option, either repair the defective equipment or replace it with a remanufactured unit. This repair will be done for a fixed charge. For information on this charge, please call or write to the address given below.

Comdial
1180 Seminole Trail
P.O. Box 7266
Charlottesville, VA 22906-7266
Attention: Repair Department
Telephone: (804) 978-2400

When returning equipment for repair, pack it carefully to prevent damage. Any damages during shipment will be the responsibility of the purchaser. The equipment should be shipped freight or postage prepaid.

FUSE LOCATION

The system is protected against short circuit damage by fuses located on the power supply chassis. Fuse location and values are as shown in Figure 4-1. Always replace a fuse with one of the same value and type, otherwise, equipment damage could result.




Figure 4-1. Fuse Locations And Values

FAILURE ISOLATION

Wiring

Refer to the installation check out procedure for instructions for testing the system wiring for possible failure.

System Status Indicators

The power supply contains five red LED indicators. When these LEDs are on, they indicate that their corresponding power supply voltages are operational.

A red LED located near the cassette/music port is the system status indicator. This indicator is turned on steady when power is applied to the KSU. If the indicator flashes after power up, it could be indicating a processor failure. Unplug and reconnect the AC power to the power supply and observe the LED indication. If it still shows a flashing indication, refer to Figure 4-2.

Station Self Test

The multiline stations can be self tested for proper operation per the following instructions.

1. Disconnect the line cord at the station base.

IMPORTANT NOTE

THE ADJACENT ODD OK EVEN STATION WILL BE DISABLED DURING THE TIME THAT THE STATION LINE CORD IS BEING DISCONNECTED OR RECONNECTED.

2. Press and hold the MUTE key, and reconnect the line cord to the station connector. The station will automatically perform a Self test routine. Release the MUTE key as soon as the test begins. The sequence of the test is as follows:

3 AND 8 LINE KEYSSET

SEQUENCE	INDICATION
1	B-Field indicators light in turn and stay on
2	ITCM indicator lights
3	MONITOR indicator lights
4	All indicators extinguish in same order as lighted
5	Ringer sounds (be sure volume is set to med. or high)

22 LINE/FEATURE KEYSSET

SEQUENCE	INDICATION
1	MONITOR indicator lights
2	B-Field indicators light in turn and stay on
3	HOLD indicator lights
4	ITCM indicator lights
5	A-Field indicators light in turn and stay on
6	All indicators extinguish
7	Ringer sounds (be sure volume is set to med. or high)

3. Replace any station that does not pass the self test.

DSS/BLF Console Self Test

Test the DSS/BLF Console for proper lamp operation per the following procedure.

1. Disconnect the console line cord plug from the line.
2. Press and hold console key C10 while reconnecting the line cord plug to the line.

IMPORTANT NOTE

THE COMPANION STATION WILL BE DISABLED DURING THE TIME THAT THE CONSOLE IS BEING DISCONNECTED AND RECONNECTED.

3. Release console key **C10**, and note that the BLF indicators will each turn on in sequence beginning with the station 10 indicator. The indicators will then turn off and the console will become operational.

Paired Stations

Station ports 10 through 41 are paired for data and for overload protection as shown below. Console ports 10a and 11a are not paired with any other port.

DATA PAIRING

10 - 11
 CON 10a
 12 - 13
 CON 11a
 14 - 15
 16 - 17
 18 - 19
 20 - 21
 22 - 23
 24 - 25
 26 - 27
 28 - 29
 30 - 31
 32 - 33
 34 - 35
 36 - 37
 38 - 39
 40 - 41

OVERLOAD PAIRING

10 - 12
 11 - 13
 14 - 16
 15 - 17
 18 - 20
 19 - 21
 22 - 24
 23 - 25
 26 - 28
 27 - 29
 30 - 32
 31 - 33
 34 - 36
 35 - 37
 38 - 40
 39 - 41

If erratic light indications or ring signals occur at a paired station, an open data pair at either station **may be** the fault. A station with an open data line may work properly on a short loop but fail on a long loop. Test the wiring of stations showing this symptom per the checkout procedure given in Chapter 2.

If a fault occurs which **causes** more than 300 **ma.** of current to **be** drawn, the overload paired stations are disabled by circuit action. Disconnect the disabled stations and reconnect them one at a time to isolate the faulty one.

Failure Analysis

KSU And Station

Figure 4-2 details a failure analysis flow chart to assist a service technician in isolating a failure in a defective system. One way to isolate a failure is to **substitute** a known good assembly for a suspected one. This is the recommended failure isolation method to **use** with the system.

Connecting and disconnecting stations to the **system** does not affect the stored station auto/speed dial memory data. This data is stored in the KSU memory and not at the individual stations. Replacing the KSU, however, **causes** all stored memory to be lost. This includes all memory dialing numbers as well as all COS programming data.




Figure 4-2. Failure Analysis Flow Chart

DESK/WALL REVERSAL AND WALL MOUNTING
(22 Line/Feature **Keyset** and Single-Line **Keyset**, Only)

Conversion

To convert a station from a standard desk model to one which can be hung on the wall, follow the procedure outlined below.

1. Remove and discard the pull out directory (22 Line/Feature **Keyset**, only).
2. Remove the lower housing of the station, and rotate it 180 degrees.

CAUTION

The PWB contains circuitry which is sensitive to static electricity discharge. Be sure that your body and the workplace are properly grounded to avoid any static electricity discharge while performing the desk/wall reversal.

3. Remove the knockouts from the desired mounting holes as illustrated in Figure 4-3.
4. Replace the lower housing. Make sure that all wires are clear.

Wall Mounting

Mount the station directly on the wall using two, **#10, panhead** screws (obtained locally), or mount it on a wall jack cover plate.

1. Thread the **#10** screws into the wall within **1/8-inch** of the surface. Refer to Figure 4-3 for the spacing dimensions.
2. Insure that the housing is converted properly for a wall mounting installation (see above instructions).
3. Pull out the latching lever.
4. Position the keyhole shaped holes in the bottom of the station over the **#10** screws or the cover plate studs. Slide the station down until a slight click is felt.
5. Push the latching lever in to lock the station in place.
6. To remove the station, pull out the latching lever, lift to unsnap both screws or studs from the bottom housing, and lift the **station** away from the wall.




Figure 4-3. Station Wall Mounting Details
 (Note: 22 Line/Feature Keyset shown - Single-Line Keyset similar)

REPLACEMENT PARTS LIST

<u>ORDER CODE</u>	<u>DESCRIPTION OF PART</u>
2232 KSU	Key Service Unit, 22 Lines, 32 Stations
2232-PS	Power supply Assembly - Required with 2232 KSU
	22 Line/Feature Keyset Desk/Wall Reversible:
3500-XX-CT-000S	Speakerphone, 10x14 Key Field
3502-XX-CT-000M	Monitor, 10x14 Key Field
3614-XX-CT-000M	Monitor, 10x14 Key Field
3614-XX-CT-000S	Speakerphone, 10x14 Key Field
3614-XX-CT-LCDS	Speakerphone, 10x14 Key Field, LCD Display
3614-XX-DG-000M	Monitor, 10x14 Key Field, Data Jack
3614-XX-DG-000S	Speakerphone, 10x14 Key Field, Data Jack
3614-XX-DG-LCDS	Speakerphone, 10x14 Key Field, Data Jack, LCD Display
3620-XX-DG-000M	Monitor, 5x20 Key Field, Data Jack
3620-XX-DG-000S	Speakerphone, 5x20 Key Field, Data Jack
3622-XX-CT-000M	Monitor, 2x22 Key Field
3622-XX-CT-000S	Speakerphone, 2x22 Key Field
3622-XX-DG-000M	Monitor, 2x22 Key Field
3622-XX-DG-000S	Speakerphone, 2x22 Key Field
	Single-Line Keyset (Proprietary); Desk/Wall
	Reversible:
3600-XX-CT-000M	Message Waiting Light, Hold Key
3600-XX-CT-009M	Message Waiting Light
3600-XX-CT-579M	Message Waiting Light, Hold Key, Tap Key
	DSS/BLF Console:
DSS-BLF-32-XX	32-Key DSS, 32-LED BLF
DSS-BLF-40-XX	40-Key DSS, 40-LED BLF
DSS-BLF-70-XX	70-Key DSS, 70-LED BLF
KA-M-xx	Handset
	Handset Cord
H4DU-6-M-xx	6-foot length
H4DU-9-M-xx	9-foot length
H4DU-12-M-xx	12-foot length
	Line Cord, 6-Wire , Flat
703508-868	10-Inch
703027-040	-?-Foot
703027-027	14-Foot
703508-867	25-foot
703500-550	Cable Assembly, Data Printer
703508-869	Designation Strip Package, includes 50 number cards 50 autodial index cards/design. strips 50 pull-out reference index cards 5 number card covers 5 autodial index covers 5 designation strip covers
703500-560	Lens Assembly, Pull Out Directory

xx = COLOR (See parts catalog for details)

A-LEAD CONTROL DEVICE CONNECTIONS 2-5
 AC POWER CONNECTION 2-3
 AREA PAGING INTERFACE - LINE PORT 2-7
 AREA PAGING INTERFACE - STATION PA PORT.....2- 7
 BASE LEVEL PROGRAM ENTRY MODE 3-2
 CASSETTE TAPE RECORD OF COS VALUES 3-22
 CASSETTE TAPE RECORDER INTERFACE 2-8
 CHECK OUT 2-17
 CLASS OF SERVICE DEFAULT 3-3
 COMMON AUDIBLE AND AUXILIARY STATION INTERFACE.....2- 6
 COMPATIBILITY WITH TELEPHONE NETWORK.....i-i
 CONNECTION, AC POWER
 CONNECTIONS, A-LEAD CONTROL DEVICE 2-5
 CONNECTIONS, DATA DEVICE 2-5
 CONNECTIONS, DSS/BLF CONSOLE 2-4
 CONNECTIONS, LINE 2-3
 CONNECTIONS, POWER FAILURE STATIONS 2-4
 CONNECTIONS, STATION AUXILIARY JACK 2-4
 CONNECTIONS, STATION 2-3
 CONVERSION, DESK/WALL OF STATIONS 4-5
 COS PRINTOUT 3-20
 DATA DEVICE CONNECTIONS 2-5
 DEFAULT, CLASS OF SERVICE 3-3
 DEFAULTS, LINE 3-12
 DEFAULTS, STATION 3-14
 DEE'AULTS, SYSTEM 3-5
 DESK/WALL REVERSAL AND WALL MOUNTING, OF STATIONS.....4- 5
 DSS/BLF CONSOLE CONNECTIONS 2-4
 DSS/BLF CONSOLE SELF TEST 4-3
 DUAL REGISTRATION NOTIFICATION 1-2
 FAILURE ANALYSIS 4-5
 FAILURE ISOLATION 4-2
 FCC RULES AND REGULATIONS 1-2
 FUSE LOCATION 4-1
 GENERAL CHECK 2-18
 GENERAL INFORMATION, PROGRAMMING 3-1
 INITIAL CONDITION 2-17
 INSTALLATION REQUIREMENTS 1-3
 INSTALLATION 1-5
 INTRODUCTION.....1-1

-continued

Publication Index - continued

KEY SYSTEM/MUTIFUNCTION STRAPPING	2-8
LINE CONNECTIONS	2-3
LINE COS PROGRAMMING REFERENCE TABLE	3-13
LINE COS PROGRAMMING	3-12
LINE DEFAULTS	3-12
LIST OF ILLUSTRATIONS	v
LIST OF TABLES	v
'LOADING COS DATA FROM TAPE	3-23
MAINTENANCE	4-1
MANUAL SCOPE	1-1
MOUNTING CONSIDERATIONS	2-1
MOUNTING PROCEDURE	2-1
MULTIFUNCTION/KEY SYSTEM STRAPPING	2-8
MUSIC INTERFACE	2-8
NOTIFICATION TO TELEPHONE COMPANY	1-2
PAIRED STATIONS	4-4
PARTY LINES AND COIN LINES	1-3
POWER FAILURE STATION CONNECTIONS	2-4
PRINTOUT, COS AND SMDR DATA	3-20
PROCEDURE, LINE COS PROGRAMMING	3-12
PROCEDURE, SYSTEM COS PROGRAMMING	3-5
PROGRAMMING OVERLAYS	3-3
PROGRAMMING PROCEDURE, SYSTEM COS	3-5
PROGRAMMING, LINE COS	3-12
PROGRAMMING, STATION COS	3-14
PROGRAMMING, SYSTEM SPEED DIAL	3-25
PROGRAMMING, SYSTEM	3-1
PROGRAMMING, TOLL RESTRICTION	3-9
RADIO FREQUENCY INTERFERENCE	1-3
RECORDING COS DATA TO TAPE	3-22
RELATED INFORMATION	1-1
REPAIR AUTHORIZATION	1-3
REPAIR SERVICE	4-1
REPLACEMENT PARTS LIST	4-7
RESISTANCE CHECK	2-17
RINGER EQUIVALENCE NUMBER	1-4

Publication Index - continued

SELF TEST, DSS/BLF CONSOLE	4-3
SELF TEST, STATION	4-3
SMDR PRINTOUT	3-20
SPECIAL PROGRAMMING REQUIREMENTS FOR SINGLE-LINE KEYSETS	3- 1
STATION AUXILIARY JACK CONNECTIONS	2-4
STATION CONNECTIONS	2-3
STATION COS PROGRAMMING REFERENCE TABLE	3-19
STATION COS PROGRAMMING	3-14
STATION DEFAULTS	3-14
STATION PAIRING	4-4
STATION SELF TEST	4-3
STATION TYPES	1-2
STRAPPING KEY SYSTEM/MUTIFUNCTION	2-8
SYSTEM CHECKOUT	2-23
SYSTEM CLOCK INFORMATION	3-24
SYSTEM COS PROGRAMMING PROCEDURE	3-5
SYSTEM COS PROGRAMMING REFERENCE TABLE	3- 5
SYSTEM DEFAULTS	3-5
SYSTEM GROUNDING	2-6
SYSTEM PROGRAMMING	3-1
SYSTEM SPEED DIAL PROGRAMMING	3-25
SYSTEM STATUS INDICATORS	4-3
SYSTEM WIRING	2-3
TABLE ENTRY PROCEDURE, TOLL RESTRICTION	3- 7
TABLE OF CONTENTS1 v
TECHNICAL ASSISTANCE AND REPAIR SERVICE	4- 1
TECHNICAL ASSISTANCE	4-1
TOLL RESTRICTION PROGRAMMING PROCEDURE	3-10
TOLL RESTRICTION PROGRAMMING REFERENCE TABLES	3-10
TOLL RESTRICTION PROGRAMMING	3-7
TROUBLESHOOTING	1-3
VOLTAGE CHECK	2-18
WALL MOUNTING, OF STATIONS	4-5

-end

READERS COMMENT FORM

Cut along Line

Publication No. _____ Issue No. _____ Addendum _____

Title _____

How did you use this publication?

- Product familiarization
- Installation

- CI Training
- Maintenance

Other _____

Please check specific criticism(s), give page number(s), and explain below:

- Clarification on page(s) _____
- Addition on page(s) _____
- Error on page(s) _____
- Deletion on page(s) _____

Comments: _____

Thank you for your cooperation. If a reply is required, please check:

Name _____ Date _____

Your Function _____

Company _____

Address _____

City, State _____ Zip _____

Cut Along Line


Please Tape — Do Not Staple

COMDIAL

Made right in the USA

Cut Along Line

Fold



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY MAIL
FIRST CLASS MAIL PERMIT NO.594
CHARLOTTESVILLE, VA 22906

POSTAGE WILL BE PAID BY ADDRESSEE

COMDIAL
TECHNICAL PUBLICATIONS DEPARTMENT
P O BOX 7266
CHARLOTTESVILLE VA 22906-7266



Fold

Cut Along Line

Please Tape — Do Not Staple

LIMITED WARRANTY

Comdial Corporation (Comdial) warrants that under normal operating conditions, this Equipment (except for fuses, lamps, and other consumables) will be free from defects in material and workmanship for a period of twenty-four (24) months from the manufacturing date stamped on the Equipment. Comdial's sole obligation under this warranty or under any other legal obligation with respect to the Equipment is to repair or replace, at its option, the Equipment if it is deemed defective by Comdial during the warranty period free of charge with new or refurbished equipment or parts, at Comdial's option, when the Equipment is returned to Comdial, freight or postage prepaid, during the warranty period. This warranty does not apply if, in the sole judgement of Comdial, the Equipment has been installed or used in combination or in assembly with products not supplied by Comdial and which are not compatible or inferior quality, design or performance, or the Equipment has been otherwise misused, abused, accidentally damaged, or damaged or malfunctions or fails to function as a result of acts of God such as fire, flood, or lightning or other incidence of excessive or insufficient voltage or failure to follow instructions. Repair or alteration of this Equipment other than as specifically authorized by Comdial or its authorized repair agent is prohibited and will void this warranty. This warranty does not cover costs associated with installation, removal, or reinstallation of the Equipment. Comdial does not warrant that the Equipment is compatible with all telephone or switching systems. THIS WARRANTY IS EXCLUSIVE, BEING IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. WITHOUT EXPANDING UPON THE FOREGOING WARRANTY, THE MAXIMUM LIABILITY OF COMDIAL UNDER ANY WARRANTY, STATUTORY, EXPRESS OR IMPLIED, IS LIMITED TO THE PURCHASE PRICE OF THE EQUIPMENT. COMDIAL SHALL HAVE NO RESPONSIBILITY FOR DAMAGE TO PROPERTY OR ANY OTHER LOSS OR INJURY, INCLUDING CONSEQUENTIAL AND/OR INCIDENTAL DAMAGES, RESULTING FROM THE POSSESSION, OPERATION OR USE OF THE EQUIPMENT. ALL SUCH CLAIMS BEING HEREBY EXPRESSLY WAIVED. THE PURCHASER'S EXCLUSIVE WARRANTY AND REMEDY SHALL BE ONLY AS STATED HEREIN.

This warranty gives you specific legal rights and you may also have other rights which may vary from state to state. Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you.

If the Magnuson-Moss Act should be held to apply to the sale of the Equipment by a court of competent jurisdiction, the implied warranty of fitness for a particular purpose shall extend for one year from the date of manufacture.

No Comdial dealer nor any other person or entity other than Comdial may extend or modify this warranty, and no such modification or extension shall be effective unless it is in writing.

This manual has been developed by Comdial Corporation (the "Company") and is intended for the use of its customers and service personnel. The information in this manual is subject to change without notice. While every effort has been made to eliminate errors, the Company disclaims liability for any difficulties arising from the interpretation of the information contained herein.

The information contained herein does not purport to cover all details or variations in equipment nor to provide for every possible contingency to be met in connection with installation, operation, or maintenance. Should further information be desired, or should particular problems arise which are not covered sufficiently for the purchaser's purposes, contact, Comdial, Customer Service Department, P.O. Box 7266, Charlottesville, Virginia 22906.

COMDIAL
Charlottesville, Va. 22901

PRINTED IN U.S.A.
716604-700.01

